





## ELECTROMECHANICAL AND ELECTRONIC THERMOSTATS

For these thermostats incorporated inside various boxes, housing and cabinets: See catalogues N°2 and 3 Explosion proof versions: See catalogue N°4

The professional solution: an extended, rational, and consistent range of products

Technical catalogue for R&D department

Edition: 20130402



JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr GENERAL: our sales are made under the here below terms of sales. Any contrary conditions provided by the buyer shall not be binding and shall not have any legal effect.

The execution and delivery of any purchase order is made in conformity with the present general terms of sales and it is noted that the buyer first has full knowledge of these terms.

In case of dispute on any of the herein below terms, we will consider ourselves as completely free from any contract related to the execution of any pending order. If some specific conditions are stated by the buyer, these conditions will be considered by us as a formal acceptance only after our written consent.

ORDER: we will commit only on orders for which an order acknowledgement has been issued. The sale is regarded executed at the date of order acceptance by JPC. Any cessation or cancellation of pending orders, for whatever reasons, cannot be accepted by JPC without a compensation equal to the ordered goods value.

Any manufactured product being subjected of a prototype or a pre-serie accepted by the customer will be regarded as in compliance with the customer's specifications.

No goods can be returned without JPC's written consent. In this case, a credit note valuable on a further purchase order will be issued only if the goods are returned in the original delivery conditions. All manufactured goods made upon a specific order cannot be either returned or be subjected to a credit note.

PRICES: our price offers are remitted under the existing conditions at the date of offer, for mentioned quantities. They can be revised after the call period has expired. Orders for lower quantities than quoted: our offers are subjected to price revisions.

Orders with prices related to our general price list can be revised at any time, in accordance to the existing terms at the delivery date. Our prices are VAT exclusive for unpacked materials according to the EXW Incoterm.

For orders less than € 75 Excl. tax exclusive of fees, administrative costs amounting to € 7.62 Excl. tax will be charged to customer.

DELIVERY TIME: our delivery times are estimated bona fide. They are purely informative and cannot be considered as commitments. Unless our prior express consent, no overrun will be regarded as a justification of order cancellation or set rights to any compensation or deduction.

DELIVERY: Whatever mean of transportation, all risk of loss or damage in transit shall be borne by the purchaser.

The buyer must ensure of the good conditions of the delivered goods and he must make, within the legal terms, all necessary reserves and legal actions in order to preserve his rights against the carrier.

Regarding the conformity and visible quality of delivered goods related to an order, the buyer must send his eventual written claim within an 8 days legal notice from the collection date. Claims will be taken into account only if the goods are kept in the consignment conditions.

For manufacturing reasons, we reserve the right of delivering plus or minus 10 percent of the ordered quantities.

PAYMENT TERMS: unless other arrangements expressly provided by special conditions at the bottom of our order acknowledgment, our invoice is resolvable by draft accepted at 30 days end of month.

The invoices less than € 150 Excl. tax, the first order and the files not accepted by our factoring company are resolvable cash on order. No discount for pre-payment is accepted.

Whatever the mean of payment, we reserve the ability of cancelling or postponing any blanket or purchase order, invoicing any related charges and to ask for an immediate payment of all pending invoices and all implemented collection charges until total settlement has been completed.

In no way, payments due to JPC can be postponed or be subjected to either deduction nor compensation unless JPC's express written consent.

We reserve the right to require an agreed guarantee of the customer's execution of commitments, even during the execution of a blanket or purchase order.

Any refuse from the customer will open JPC's right to partial or total order cancellation.

Any payment to JPC will apply to due amounts whatever the cause, starting with the oldest due amounts.

RETENTION OF PROPERTY: our goods are sold with a retention of property.: according to the terms of the 1980/05/12 Law and the 1985/01/25 Law (amended 1994/06/10), the Seller shall keep the ownership of the Products until the full payment of the agreed price is made including any other payments outstanding, if any, from the Purchaser to the Seller. However, the Purchaser shall bear the risk of the loss, damages, harms, deterioration or destruction of the sold Products since such Products are at the disposal of the Purchaser and he must have subscribed any related insurance.

In the event of payment delayed by the Purchaser and 8 days after receipt of a registered reminder letter remained unfruitful, the contract shall be regarded as executed. In such an event, JPC will reserve the right to take back the goods and all related settlements by the Purchaser will not be refunded and regarded as damages, without any restitution or compensation claim from the Purchaser related to an eventual resell.

To prevail over the aforesaid clause and in the event of collective judicial proceedings, JPC will notify its such express will to the Purchaser or to its official representative, by registered letter, to have the goods returned.

PROPERTY OF TOOLS: the tools that have been fully settled to JPC are the customer's property. They remain at his entire disposal at JPC's facility if the end product is made by JPC, or in the sub-contractor's French or Foreign facility if the product is sub-contracted or imported.

Unless otherwise written consent from the Purchaser, all tools unused for more than 2 years will be considered as abandoned and will be destroyed. Storage charges can be invoiced if the customer wishes to keep unused tools.

Tools for which a partial amount has been invoiced to the Purchaser remain the property of JPC. The tools are made to fit the manufacturing equipment, Norms or Standards in force at JPC's or at its sub-contractors. Unless otherwise specified, their lifetimes are equal to 3 years life according to the annual quantities provided by the Purchaser during original negotiation or on the original order. In the meantime, all maintenance and repairs charges shall be borne by JPC. For additional quantities than provided, all maintenance and repairs charges shall be borne by the Purchaser.

WARRANTY: goods manufactured by JPC are covered by a 1 year warranty coming into force at the delivery date.

For all imported good, our warranty period is limited to the manufacturer's warranty. We cannot be held as responsible for any manufacturing ascertained default on goods re-sold as are. We forward the claims on delivered goods and apply the eventual warranty clauses after agreement receipt from our constituents.

To benefit the warranty, The Purchaser must send a written claim to JPC, providing all ascertained defaults and give JPC all means to ascertain and bring corrective actions.

Packing, freight, return, carriage, un-assembly and re-assembly charges shall be borne by the Purchaser.

LIABILITY LIMITATIONS: the buyer must ensure that the use of the purchased products complies with Norms and Rules into force, whatever the advices or recommendations shown in the seller's documents. De facto, he resigns all claims against the Seller. No request for compensations for direct or indirect damages or loss is receivable. JPC's liability is strictly limited to the aforesaid obligations.

APPROPRIATE COURT - APPLICABLE LAWS: all sales by JPC are subjected to French Laws including the 1980 Vienna Convention on International Sales. Any controversy, dispute or claim arising out of or related to this contract or breach thereof shall be settled by arbitration of The Tribunal de Commerce Court held in Meaux, 77, France.

> JPC sas- 2 voie Gallo-Romaine - ZAC de la Bonne Rencontre - 77860 Quincy Voisins - France RCS Meaux 302 236 641 00049 - APE 2651B - FR10 302 236 641



## Summary

	Introduction to electromechanical t	hermostat technolog	у	P 3-29	
Section 1	Thermostats comparative features			P 30-32	
	References table and alphabetical ta	ble Cemperature cor	ntrol thermostats	P 33-34	
	===	Type 4N630	Waterproof flat disc thermostat, 4A 250V	P 37	
	<b>\$</b>	Туре 4911	Snap action bimetal disc thermostat, ½" disc, reduced 6 mm thickness, 10A 250V	P 38	
		Туре 4903	Snap action bimetal disc thermostat, ½" disc, 12 mm thickness, 16A 250V	P 39	embers.
		Various models	Selection of antifreeze or defrost application disc thermostat	P 40	iance me
		Туре ІВ	Surface sensing bimetal thermostat	P 41	nheat alli
	4	Type 35	Energy regulators	P 42	his catalogue are made by Ultimheat alliance members.
	5	Type 8G	16A Single pole control thermostat (Appliances type)	P 43	gue are ma
Section 2		Type KR and KU	Single pole control thermostat, standard differential and reduced differential (Commercial type)	P 44	his catalog
	*	Type 8H	30A SPNC bulb and capillary thermostats	P 45	componen
	*	Type 8J	30A DPNC bulb and capillary thermostats	P 46	, products and componen
		Type 8C	3x16A control thermostat	P 47	∢
		Type SR and SU	15A Single pole rod thermostat	P 48	Unless exceptionally specified by this logo
		Type VR and VU	15A Single pole rod thermostat with dead zone	P 49	ceptionally spe
		Type 1B, 1C, 1R, 1U	Miniature single pole and double pole rod thermostats, 16A	P 50	Unless ex
		Electronic t	hermostats		
Section 3		Type 2PE2N6	Blind electronic thermostat,16A	P 53	
		Type 2DNAP6	Digital display electronic thermostat, 16A	P 54	

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr JPC 1

## Summary

	Ν	/lanual reset and	thermal cut out	
		Type 8I	3 x 16A combination control thermostat	P 57
		Type 8L	SPNC manual reset high limit, fail safe	P 58
		Туре КХ	15A SPDT manual reset high limit, adjustable, commercial type	P 59
		Type 4R05	Manual reset Snap action bimetal disc thermostat, ½" disc	P 60
Section 4		Type 4C	3 pole manual reset disc thermostat	P 61
		Type 8X	DPNC manual reset high limit, fail safe	P 62
		Type 82	3 pole manual reset high limit, fail safe	P 63
		Type 1X and 1D	SPDT, SPNC and DPNC manual reset rod thermostat	P 64
	A CONTRACTOR OF A CONTRACTOR A	Type 5MA3	Thermal cut out, 10 and 16A 250V, in line	P 65
		Type 5MA3-F	Wired thermal cut out, 16A250V, for pocket mounting	P 66
	• • •	Thermostat acce	Thermostats Knobs	P 69
			Bezels, dials and plates	P 70
Section 5		9	Shafts gaskets and Pockets	P 71
			Pockets and pocketsgrommets	P 72
		100	Brackets, fittings and thermostats boots	P 73
		H-	Disc thermostats accessories	P 74

2

JPC

inless exceptionally specified by this logo 🖉 , products and components in this catalogue are m y Ultimheat alliance members.

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr The temperature measurement was preceded by a long period, throughout the 18th century, when first empirically and then gradually more accurately, have been developed measurement scales, were discovered fixed points for the calibration of these scales, and all physical variations related to temperature change: thermal expansion of gases, liquids, metals and other solids, liquefaction temperatures, boiling temperature, magnetism, thermoelectricity, just to give a few.

However, this is only when the shortage of charcoal, the rising price of heating means added with the need for precise temperature control, that were developed thermostats. The first one was made for incubators at the end of the 18th century, by the French engineer Jean Simon Bonnemain, with the first accurate bimetallic rod thermostat in 1788 (It was named at that time "Gouverneur du feu" or "régulateur du feu" (fire governor). It was used to control the water temperature of the first central heating boiler using the thermosyphon that he also invented.

In the first quarter of the 19th century, the huge development of the central heating by hot water or low pressure steam generalized various control systems, most of them in the low pressure steam boilers, and the arrival of electricity for domestic use in the late 19th century initiated the search for and discovery during the first 50 years of the 20th century almost all current systems thermostats

> 1788. The first rod thermostat named "Régulateur du feu" invented and built by Jean Simon Bonnemain, French engineer, to control the temperature of a Hatchery in the suburbs of Paris, heated by the first thermosyphon boiler also invented for the occasion. This is the direct ancestor of the rod thermostats made by JPC

Functional reproduction at 1/1 scale made by Ultimheat (height 900 mm)



#### 1. Temperature sensing principles

#### 1.1 Bimetals





#### **1.1.1 BIMETAL STRIPS**

The bimetal strip is formed by two co-laminated metal. One has a high coefficient of expansion, the other a lower or zero. When this strip is heated, it bends proportionally to the temperature . These bimetal blades are generally flat and fixed at one end. But they can be wound in a spiral shape, although this arrangement most often used in the construction of thermometers.

#### **1.1.2 DISCS AND DISCS VARIATIONS**





In many applications, it is needed to produce a bimetal with a snap operation with a sudden change of shape at a given temperature. For this, a bimetal disc is bumped and formed into a dome. Temperature changes cause an accumulation of energy therein, which, at a specified temperature, snaps from the concave to the convex shape. A very rigorous selection of the composition, thickness, depths of stamping and heat treatment, is requested to obtaining accurate, stable and repetitive operating temperature.

Based on original round form, were developed rectangular shapes, ovals, etc..

The main difficulty is to obtain a small tolerance and a small differential on operating temperature .

But these snap action discs are the sensing device of most temperature limiters on the market.

Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

#### **1.2 DOUBLE METAL EXPANSION**

Double metal expansion is the differential expansion of 2 different metals, not laminated together. Metal thermal expansion produces huge force, enough for example do bend railways rails when expansion gaps are not correctly designed.

#### **1.2.1 CARTRIDGES**

The cartridge consists of an outer expandable tube, usually stainless steel, and two non-expandable internal blades, usually Invar.

The elongation of the envelope is a function of temperature. For a length of about 100 mm, this expansion is 0.0020mm per ° C.

#### 1.2.2 PARALLEL BLADES

Their principle is similar to cartridges, they are made of one expandable copper alloy blade to which is welded at each of its ends a bow shaped invar blade. Expansion of the copper alloy blade will tend to reduce the distance between the two blades

#### 1.2.3 RODS

eatures used on these data sheets are for guidance only and can be modified without prior advice

Because of permanent improvement of our products, drawings,

The rods are formed of an outer expandable tube in stainless steel, copper or brass, and an inner invar rod. Expansions value are similar as the cartridges. This principle is the basis of most current water heater thermostats. This is a very simple, very reliable, the reaction time is very fast, as it is the outer tube itself that measures the temperature. Through the use of expandable metal instead of Invar, it is possible to obtain devices with anticipative control action, which is very close to proportional action of electronic controllers.

Using the same metal for the outer tube and the inner rod provides controls that are only responsive to fast changes in temperature and are used in fire detectors.

In very high temperatures, invar rod can be replaced by quartz or alumina.

#### **1.3 LIQUID EXPANSION**

Liquids are incompressible and expand as solids. The expansion forces are very important and will develop considerable power to the mechanisms.

The expansion of liquid are used in closed subassemblies named « diastats », they consist of a bulb, a capillary, a bellows or diaphragm.

The expansion of the liquid in the bulb is transmitted through the capillary to the diaphragm which inflates and produces movement. Diaphragms expansion ranges are between 0.4 and 0.8mm for the entire measuring range. Bulbs volumes are calculated to provide a specific displacement for a given range. Freezing temperature of the liquid gives the lower limit of use, the upper limit is the boiling temperature. Raising these limits generally cause the destruction of the diastat.

The good thermal conductivity of liquids used provides short response time.

#### **1.3.1 LIQUID METALS**

Mercury was the first liquid used in thermostats. Its first use was the traditional mercury thermometer.

Its expansion is almost linear from ambient to 500 ° C.

This is an excellent conductor of heat. So it was ideal for liquid thermostats. However its toxicity has done it to virtually disappear during last decade











#### 1.3.2 LIQUID METALLOIDS

Metalloids are on the borderline between metals and other materials. In thermostats, are only used sodium and potassium, and especially an eutectic mixture of the two, NaK, which as the interesting characteristic to be liquid in a wide range of temperature, from ambient temperature to over 900°C. It is also an excellent conductor of temperature.

These two characteristics have earned him to be selected as a coolant for nuclear plants.

For temperature measurement, it also has the advantage of having a linear expansion.

Its use in thermostats is relatively recent, and arose with self-cleaning ovens, because it allows devices withstanding high temperatures.

However, it must used in protected devices, without contact with air or water, because it is particularly reactive, flammable or explosive in contact with them.

It is also corrosive and requires special stainless steel diastats.

#### 1.3.3 OILS

Many oils are used. They are always a compromise between a high coefficient of expansion, which allows small bulbs, a boiling point as high as possible, a freezing temperature as low as possible, a good linearity in the range expansion, a good thermal conductivity, and non-toxicity. Among the most common, we must mention the xylols, oils used in heat exchangers, and silicone oils.

It is now possible to cover with these 3 types of liquids, ranges from -40  $^\circ$  C to 400  $^\circ$  C.

#### 1.3.4 The thermal drift (Correction factor) of liquid filled bulb and capillary thermostats



#### The bulb and capillary thermostats have a closed subassembly called "Diastat".

This diastat, with bulb and capillary made of copper or stainless steel, is composed of 3 parts welded together:

1. The bulb (A), which is the reservoir of the largest portion of the liquid, and witch expansion as a function of temperature will be used to measure it. It is closed at its free end by welding after liquid filling.

2. The capillary (B), whose outer diameter varies depending on the manufacturer and type of thermostat, between 1 mm and 3 mm, which serves to transmit remotely the increase in volume of the liquid in the bulb

3. The bellows (C), consisting of two flexible cups welded together on their edges, having a diameter of 19 to 25 mm (sometimes up to 32 mm on industrial devices), which will convert the increase of the bulb liquid volume into mechanical displacement (e) These three parts are filled with a liquid under vacuum. The expansion of the liquid, proportional to the temperature increase, causes the displacement "e", which is used to operate an electrical contact.

However, the expansion of the liquid in the capillary (B) and into the bellows (C) is not related to the temperature measured by the sensor (A), but to room temperature in which they are located, and cause therefore a parasite expansion of the liquid and therefore an unwanted mechanical displacement.

The design of a diastat tends to minimize this movement, by limiting the volume of liquid in (C) and (D) by 2 ways:

• By limiting the capillary internal diameter. The minimum diameter is a compromise between the technological possibilities of embodiment of the capillaries, the stresses due to bending of the capillary, and the water pressure losses permissible depending on the viscosity of the liquid used, and the pressure developed by the expansion.

• On the bellows: When filling the diastat, the two membranes forming the bellows are pressed against each other, without gap, and thus only a small amount of fluid can go between them. However the volume of liquid in the bellows increases progressively as the liquid in the bulb (A) expands by the temperature rise. The ratio of the drift therefore not only reports to the initial volume inside the bellow, but increase with the temperatures as this volume increases with the temperature rise on the bulb.

The counterpart of this design of the bellows with a small amount of liquid when filling the diastat is that no mechanical movement is possible below this filling temperature. In assembled thermostats, adjusting the set point is not possible below this temperature at which the bellows is empty. This area below the filling temperature is called "dead zone", and typically corresponds to an area where no temperature is printed on the thermostat knob.

The parasite drift of a bulb and capillary thermostat will be given in the data sheet and expressed in ° C / ° C or ° K / ° K

It depends on the volume ratio between the bulb and capillary + bellows. A large volume bulb is less sensitive to drift, and a short capillary also decreases it.

In the case of fixed temperature high limit thermostat, the small bulbs will lead to a high sensitivity to the ambient temperature on the thermostat body.





Comparative values for thermal drift in a dia. 19 mm membrane diastat, and a displacement "e" of 0.8 mm for the temperature span (approximate values)

Temperature range	Drift with 250 mm capillary (°K/°K)	Drift with 900 mm capillary (°K/°K)	Drift with 900 mm capillary (°K/°K)
4-40°C	0.1	0.12	0.14
30-90°C	0.18	0.20	0.24
50-300°C	0.25	0.45	0.58

This drift explains that thermostats calibration temperature are given for a body ambient temperature of 23°C+/-2°C (standard ambient condition given by EN60068-1), and usually for an immersed capillary length of 80 to 100 mm

Examples of temperature drift on a thermostat with a 1.5 m capillary (to be added to calibration tolerances)

Temperature range (°C)	Set point temperature (°C)	Effective contact opening temperature if ambient on thermostat body is 0°C	Effective contact opening temperature if ambient on thermostat body is 50°C
4-40	40	40+3,2	40-3,8
30-90	90	90+5,5	90-6,5
50-300	300	300+13,3	300-15,7

#### **1.4 VAPOR PRESSURE**

This system involves in diastats a mix of liquid and its saturated vapor , just as in a butane bottle, where are coexisting gas and liquid.

In this closed environment, any increase in temperature results in an increase in pressure and significant volume changes.

Unfortunately gases are compressible, and even if it is possible to obtain significant movements, the available force is low. Movements are not linear, and these systems are sensitive to changes in atmospheric pressure. Among the main fillers used, there are :

#### 1.4.1 FREONS

Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

They are used because of their availability, and existing vacuum filling systems for refrigerant circuits. They also work in low temperatures.





#### **1.4.2 BUTANE AND PROPANE**

They are used for the same reasons as above, but have the disadvantage of being flammable.

#### **1.4.3 OTHERS: METHYL CHLORIDES**

They are used in capillary thermostats and membranes room thermostat





#### **1.5 STATE CHANGE**

In state change devices, a linear displacement against temperature it not used. What is used is the instant change of volume that appears at specific temperatures at melting, freezing, and boiling points on various elements.

For example, the freezing point of water at 0 ° C causes an increase in volume, melting at 0 ° C causes a reduction in volume, but also the transition from the solid state to the liquid state : when water is boiling at 100 ° C steam causes large volume increase.

State change systems will therefore use these special properties of a number of elements and compounds.

#### **1.5.1 WAXES**

Thermostatic wax is a complex mixture of many components providing a different Melting / Freezing temperature depending on the composition. At this temperature there occurs a high volume change. Waxes have the characteristic increase in volume when they melt.

This system, which causes a high displacement, is used for car thermostats, to open the flow path of water. It is also common in central heating radiators thermostat, as well as in mini-jacks locking the doors of ovens, washing machines and other appliances.

#### **1.5.2 LOW FUSE TEMPERATURE ALLOYS**

These fusible alloys are all descendants of those discovered by Darcey at the beginning of the nineteenth century. An alloy of tin, antimony, lead, bismuth and other metals, will have melting temperatures between 25 and 200 ° C depending of the percentage of each ingredient.

Their first applications were opening the steam pressure locomotive blowdown valve. The melting of the alloy at a predetermined temperature is used to release a mechanical system (fire fusible links) or directly open an electrical circuit (thermal cut-out electrical fuses ).

#### 1.5.3 BOILING

The boiling of a liquid causes, in a closed circuit, a sharp increase in pressure. This increase in pressure may be due to local boiling in a capillary thermostat diastat. This allows to make thermostats sensitive to temperature on a long distance, detecting hot spot at any place on the capillary.

Boiling is also used in glass bulbs, which breaks when the liquid inside boils and releases a mechanical or electrical system. The best-known application is the control of the "sprinkler" systems, common in building fire detection.

#### **1.6 OTHER SYSTEMS**

#### **1.6.1 THE CURIE POINT**

The Curie temperature is the temperature at which a magnet loses its magnetization. This temperature can be changed by altering the composition of the magnetic alloy. This loss of magnetization releases a mechanical or electrical system.

This application is limited to a few specific uses, such as rice cookers

#### **1.6.2 FORM MEMORY**

Some alloys or compounds, subject to a certain temperature, return to the form they had before their mechanical processing. Heat treatment and composition determine these temperatures.

#### **1.6.3 EXPANSION OF GAS**

This system is mainly used for the production of thermometer, because the available forces are weak and can hardly operate a contact. Is linear expansion and allows a linear scale in a wide range of temperatures.

The gases used are mainly helium and argon

These systems are sensitive to atmospheric pressure and demand a compensation system









products and components in this catalogue are made by Ultimheat alliance members Unless exceptionally specified by this logo



#### 2. ELECTRICAL CONTACTS









As numerous mechanisms exist, we decided not to distinguish on the basis of constructive technique, but according to their operation speed, which is the key element.

### 2.1 ELECTRICAL CONTACTS SYSTEMS

#### 2.1.1 SLOW BREAK

In slow break contacts both sides deviate slowly at speeds of the order of 1/10 mm per second. In the normal atmosphere, then an electrical arc occurs when the contacts are close together. The duration of this arc is a function of voltage.

For voltages up to 24V DC or 110VAC, the duration of this arc is short, less than 0.1s.

For higher voltages, the arc lasts much longer, producing premature fusion of the contact, and many radio interference.

This is why it is not recommended, despite the mechanical advantages (simplicity, low cost, high precision), to use slow break (or slow make) contact in 230V electrical circuits, for fast cycling applications.

#### 2.1.2 SNAP ACTION

On snap action contacts, the gap between contacts occurs at much higher speed, of about 1m per second (100,000 times faster than a slow break contact). The contacts spacing to extinguish the electrical arc is reached in less than 1/1000 sec. There is no radio interference, and the contact does not substantially deteriorate.

This type of contact is mechanically much more complicated, more expensive, and does not allow small differential control. It is particularly suitable for control devices in 240V or 400V. Several techniques are used to get a snap action:

The oldest is the use of magnets on the contact blades. The magnetic field decreases with the

4th power of distance. The attraction between the two blades thus takes a very short distance. This system is highly reliable, but not currently used due to the large number of components that it requests.

It was used extensively on the needle contacts on barometers, manometers, thermometers with a circular dial, and was the first snap action system to be used in thermostats

• The most common today is the energy storage blade, whose drawings have been are simplified in recent years, largely due to the improvement of beryllium copper alloys, and new design concepts.





#### 2.2 CONSTRUCTION

#### 2.2.1 MATERIAL CONTACT

Before the development of silver electrical contacts, the first electric thermostats used mercury. Liquid mercury, enclosed in a glass bulb having two electrodes, established the contact between them by tilting, or more simply, a metal needle, by its movement, established the contact with the surface of the mercury.

Electrical contacts are currently rivets made of pure silver, or slightly alloyed with other metals or oxides (Cadmium, Nickel, Tin,)

Silver was chosen because it is the best known conductor of heat and electricity. Contact wears by micro vaporization at each open and close cycle. This vaporization is proportional to the strength and duration of the electric arc.

The thermal conductivity of the silver allows it to quickly evacuate the peak temperature occurring during opening of the contacts.

Its very good electrical conductivity allows for devices with very low contact resistance, generally less than 3 milliohms.

However it is not stainless and is gradually covered by a thin layer of silver oxide which is not electrically conductive.

This layer is easily vaporized during use in common household voltages (120V, 230V). However, for use in low voltage (less than 12V) and very low currents (a few milliamperes), the arc created when opening the contact is not sufficient to vaporize the contact.

This is the reason why, for low-power circuits, the contacts are protected against the oxidation by a thin layer of gold.

#### 2.2.2 CONTACT GAP

products and components in this catalogue are made by Ultimheat alliance members

After opening, the contacts are spaced by a gap. This gap, according to the device may vary from 1/10th to 3mm or more. An usual value in thermostats is 0.3 to 0.4 mm, which corresponds to micro-disconnection requested by electrical standards. Smaller gap, which is the mechanical requirement to make low differential devices (see definition belows) cannot be used in high

voltages, because, although there is no mechanical contact between the 2 contacts, an electrical arc can spontaneously appears in 380 or higher voltages: just adverse weather conditions such as high relative humidity may be sufficient.

A method to increase the contacts gap without requiring thermostats to provide significant movement, is the double break, used on some manual reset thermostats, which also reduces the risk of contact welding

#### **2.3 CONDITIONS OF USE AND ELECTRICAL LIFE**

In the specifications for an electromechanical thermostat, the expected life is described in terms of mechanical and electrical. **Electrical life :** 

This is specified as a minimum number of cycles (action of opening and closing) will make, carry, and break the specified load without contact sticking or welding, and without exceeding the electrical specifications of the device. **Mechanical life:** 

This is the number of operations which a thermostat can be expected to perform while maintaining mechanical integrity. Mechanical life is normally tested with no load or voltage applied to the power contacts, and is not part of this document.

Switch performance is influenced by a variety of factors, including: frequency of operation, type of load, temperature, humidity, altitude. Electrical ratings are been tentatively standardized in UL 1054, CSA22.55 or IEC61058-1 (Switches for appliances). IEC60730-x standards have specified testing methods and preferred electrical life classes for electrical control and safety switches. These life classes are (cycles):

300 000, 200 000, 100 000, 30 000, 20 000, 10 000, 6 000, 3 000 (1), 1000(1), 300 (2), 30(2)(4), 1(3).

1) Not applicable to thermostats or to other fast cycling actions.

2) Applicable only to manual reset.

3) Applicable only to actions which require the replacement of a part after each operation.

4) Can only be reset during manufacturer servicing.

The rating tables should be considered as working maximum for most applications. Hereunder are given some limitations that apply when they are used in other loads and voltages.

The current rating of thermostat switches is given in their technical data sheets for a resistive load in 250 or (and) 400V AC and a specified number of operations. When there is enough room, these values are printed on the product. In most of case, only the minimum mandatory information is printed. The cycle number is exceptionally printed, but this is one of the most critical parameter to estimate the expected life of the thermostat.



2.3.1 Explanation of printed values made on a thermostat upon IEC60-730-1 § 7-2

 Image: Constraint of the state of

1: Identification of terminals that are suitable for the connection of external conductors, and if they are suitable for line or neutral conductors, or both.

L= must be used for line in United Kingdom, other countries no restriction. N must be used if the terminals must be used for neutral (All countries)

2: Manufacturer's name or trade mark

3: Inductive load rating with power factor = 0.6 (When inductive load value is not printed, these contacts may be used for an inductive load, provided that the power factor is not less than 0,8, and the inductive load does not exceed 60 % of the current rating provided for the resistive load.)

4: Resistive load rating with power factor = 0.95+/-0.05

5: Degree of protection provided by enclosure, does not apply to controls or parts thereof classified as IP00, IP10, IP20, IP30 and IP40.

6: High temperature limits of the switch head (Tmax), if other than 55 °C.

7: Low temperature limits of the switch head, if lower than 0 °C

8: Ground terminal identification (if existing)

9: Unique type reference

descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

drawings,

products,

improvement of our

10: Rated voltage or rated voltage range in volts (V) (Frequency printing is mandatory if other than for range 50 Hz to 60 Hz inclusive)

11: Micro-disconnection (reduced contact gap) Printing is not mandatory.

12: Number of cycles of actuation for each manual action (For manual reset thermostat).

Number of automatic cycles for each automatic action (for control thermostat). Printing is not mandatory

13: For use on alternative circuit, 50 to 60Hz inclusive

14: Temperature limits of mounting surfaces (Ts) if more than 20 K above Tmax

#### 2.3.2 VOLTAGE, RESISTIVE OR INDUCTIVE CIRCUIT, SHIFTING ANGLE (cos phi)

In Europe, the most common voltage is 230 Volts AC 50Hz. In general, all devices are designed for these conditions. 400V operation must match particular contact spacing. However, particular attention must be given to the type of load to control: Electrical ratings are always given for a resistive load (cos phi = 1). Applications with inductive loads like motors, transformers, coils, ballast, or capacitive loads, like capacitors on one or 2 speed motors cause much more important electrical arcing between contacts. These inductive or capacitive loads severely limit the contact rating.





Overvoltage peak on inductive load circuits

When a switch breaks an inductive load, a fairly high counter electromotive force (counter emf) is generated in the switch's contact circuit. The higher the counter emf, the greater the damage to the contacts.

The quantity of electrical current which flows through the contact directly influences the contact's life. Impulse voltage is the critical value which the switch must withstand when the voltage surges momentarily due to switching an inductive load. They generate a current surge wave, witch form has generally a pulse width of 20 to 50 µs. Surge pulse rating is specified by its intensity and its width. Pulse width is time measured from pulse start to decrease to 50% of its maximum current value. Figure shows a 8/20µs rated curve.

#### Motors loads impulse voltage:

During start-up, a motor can pull 600% or more of its running current. Thus, a 3 amp motor may actually pull 18 amps or more during start-up. Additionally, when disconnected, a motor acts as a voltage generator as it slows to a stop. Depending on the motor, it can feed back into the circuit voltage well in excess of rated line voltage. These voltages appearing across the separating contacts can cause a destructive arc to exist between the contacts, which can lead to early failure of the contact

#### Lamp loads impulse voltage:

A tungsten filament lamp, when filament is cold, has an initial inrush current of 10 to 15 time the nominal current.

#### Transformers inductive loads:

When power is removed from a transformer, its core may contain remanent magnetism. If power is reapplied when voltage is of the same polarity as that of the remanent magnetism, the core may go into saturation during the first half-cycle of reapplied power. As a result, inductance will be minimal and an inrush current of perhaps 1,000% may exist for a few cycles until the core comes out of saturation. Also, as with motor loads, when power is removed from a transformer, the transformer will develop a counter voltage which can cause a destructive arc to exist between separating contacts.

#### Distributed line capacitance loads:

This occurs when a switch is located a considerable distance from the load to be switched. The instant the contacts close, distributed line capacitance charges before load current flows. This capacitance can appear as an initial short circuit to the contacts, and can pull a current well in excess of load current.

Unless exceptionally specified by this logo

products and components in this catalogue are made by Ultimheat alliance members.



#### Average inductive loads correction factor (if no arc suppression device is used)

#### Self-regulating cables inrush current surge

This is a completely different effect than short transient currents due to the contact switching interaction with the load. This current surge is due to the PTC design of self-regulating cable and takes several minutes to dissipate.

Often the heating cable will be at a relatively low temperature (and hence low resistance) when initially energized. The low resistance will thus draw a high start-up current, inversely proportional to the ambient temperature. It can reach 2 times the nominal value given at 25°C by the manufacturer

Refer to records of cable manufacturers to check the inrush current value.



	Resistive load	Filament lamp**	Electromagnetic coil	Transformer	Single phase motor	Three phase motor	Self-regulating heating cables*
	1	0.8	0.5	0.5	0.12/0.24	0.18/0.33	0.6
1 0.8 0.5 0.5 0.12/0.24 0.18/0.33 0.6							

\* Average value, depending on cable ambient temperature at startup, see the manufacturers manuals and Standard CEI60898
\*\* with hot filament

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr

13



#### Average electrical life of a thermostat switch rated 15A250V, 300.000 cycles

Average approximate values for a snap action mechanism with silver contacts.

Characteristic points:

A: Zone of mechanical break of the contact blade by metal fatigue

B: Contacts fast melting zone due to combination o inductive current, high voltage and high intensity

C: Zone of contacts rapid deterioration due to huge arcs

D: Zone of contact damage due to heating of the contact blade by the Joule effect and the loss of its elastic characteristics, combined with the electrical arcs

#### 2.3.3 AC AND DC

In the alternative current, the voltage crosses zero in each cycle, causing the arc extinction.

In DC circuits the contact does not pass a zero voltage.

So, the arc will extinguish only when the contacts gap becomes large enough to break the arc (a phenomenon used in arc welding equipment).

In thermostats the contact gap is generally low, from 0.3 to 0.5 mm.

In voltages higher than 48VDC, this contact gap is insufficient to extinguish the arc, which continues through the electrical conductivity of the ionized air caused by the passage of current.

Contacts wearing is then extremely fast, and contacts can melt or weld in a few cycles, because the unidirectional flow of current causes a transfer of metal between the contacts

Any application requiring the use of a thermostat in a DC circuit above 48V should be studied carefully, in collaboration with the supplier of the thermostat, so that reliable technical solutions (increased contact gap, magnetic blow of the arc or other contact protection) can be implemented.

#### DC Indicative breaking capacities reduction on snap action silver contacts, with the same lifetime, in resistive circuit

	· · · · · · · · · · · · · · · · · · ·		
Current	0.2 mm contact gap	0.25 mm contact gap	0.5 mm contact gap
AC, 250V	15	15	15
DC, 8V	15	15	15
DC, 30V	2	2	6
DC, 120V	0.4	0.4	0.5
DC, 230V	0.2	0.2	0.25

#### **HIGH FREQUENCY**

High frequency applications should be avoided, because they initiate overheating loops in contact blades, which anneals them and modify their flexibility. The contact blade loses its snap action contact and contacts weld or have a premature wear

#### 2.3.4 CYCLING SPEED AND NUMBER OF CYCLES

Electrical contact life is, as we have seen above, the result of many factors.

It is important that the contact has time to evacuate the heat due to the electric arc. Too fast cycling (more than 0.5 per second) cause premature wear, since the contact can not evacuate the rise in temperature.

Most thermostats are designed to withstand:

- 100 000 cycles in control devices.
- 10 000 cycles in safety devices.

In some applications the number of cycles can be much lower. A device designed to withstand 100,000 cycles at 1A can withstand 25A for a few hundred cycles, and even 100 or 150A for 1 cycle.

Expected life and cycle is a very important parameter to know for the determination of a thermostat.

#### 2.3.5 CONTACTS PROTECTION (capacitors, filters, varistors, magnetic blow)

It is possible, by means of accessories external to the contact, to extend or improve its longevity.

These systems are all designed to limit the duration of the arc.

•The oldest is the capacity mounted in parallel to the contact, which allows to use it in DC. This solution was extensively used some decades ago, when there were still domestic DC power supply. It is effective and inexpensive.

•The filter (Inductance and capacitor assembly) is mainly used on slow break contacts to avoid radio interference. It significantly increases the electrical life.

• More recently discovered, Varistors, absorb surges created by contact opening, and limit the arc duration and intensity. They double or triple the life, especially in inductive circuits.

• The magnetic blow, little used, is intended only for DC currents. A strong magnet located around the contact area, deviates the ionized arc, and makes a longer path that extinguishes the arc. This is the solution for high power ratings in 120 and 230V DC loads.

• Inductance: This system is mounted in series with the switch in the immediate vicinity of the contact. When it is well engineered, it has a smoothing effect on the voltage peaks

#### **2.3.6 CONTACTS CONTAMINATION**

The presence in the atmosphere of a number of chemicals may have an adverse effect on the contacts operation and life. In particular:

- A high relative humidity: more intense arcs, because the air loses some of its insulating properties
- Presence of ammonia : oxidation of contact blades, which are made of copper alloys.
- Presence of silicone oil or vapors: silicone on the contacts stops the electrical current, because when silicone is burned by the
- electric arc, it becomes silica (aluminum oxide), which is a high temperature resistant insulator.

#### 2.3.7 CONTACT SYSTEMS CROSSED BY THE CURRENT

In some small devices (temperature limiting), the contact mounted bimetal strips are themselves the temperature sensing elements.

These strips are not, because of their composition, very good conductors of electricity. The current flow in them causes them to heat by Joule's effect, and this temperature comes to be added to the temperature measurement. This is named « current sensitivity » and « thermal drift » in calibration.

#### 2.3.7 CONTACTS OXIDATION

We have seen above that the contact resistance was very low, of the order of a few milli-ohms. Whatever the current passing through it, the resistance is too low to cause significant heating. However, if for one reason or another (contamination, oxidation, insufficient contact pressure, mechanical deformation, etc..), the contact resistance increases, this resistance will heat the contacts if the current is high, and may overheat them enough to melt or burn flammable materials located nearby.



#### 2.4 CONTROL ACTIONS

#### 2.4.1 TEMPERATURE CONTROL

This the first function of a thermostat. A temperature control action contact is a contact that will cycle periodically, by opening and closing an electrical circuit. This is not a safety device. Contacts must withstand a high number of cycles.

#### 2.4.2 THE AUTOMATIC RESET

The automatic reset is a temperature limiter function that does not require, in case of tripping, the intervention of an operator. This type of contact is intended to warn of a malfunction and avoid product destruction if the control device is not working or broken. It resets when the temperature returns to permitted limits.

The current number of cycles of operation of this type of action is between 300 and 10 000.

#### 2.4.3 THE MANUAL RESET

A manual reset is a temperature limiting function, which requires, in case of tripping, the intervention of an operator to reset the device. This type of contact is intended to warn of a malfunction and protect the product by shut off the electrical power. The reset can be done when the temperature is returned to the authorized limits. Manual reset can be accessed or hidden. In general, they cannot be reset without using a tool or without removing a cover or a cap.

The current number of cycles of operation of this type of action is between 300 and 10 000.

#### 2.4.4 ELECTRICAL RESET

This is the same function as above, but there is no reset button. It automatically resets after disconnection of the power supply.

#### 2.4.5 RESET BY TEMPERATURE DROP

Temperature drop reset is an automatic reset after a significant drop in temperature, generally close to the ambient temperature. This solution is very little used.

#### 2.4.6 THE "ONE SHOT"

The "one shot" is a type of contact that can only be opened once. Its use is typically that of ultimate safety device, which definitely cut the power supply. Restarting the application needs a full replacement of it. Its number of operating cycles is 1. This function can be performed by metal alloy melting, plastic pellet melting, glass bead break, triggering of a bimetal disc whose return to the starting position is not possible even in the coldest ambient temperatures

#### 2.4.7 FAIL SAFE

products and components in this catalogue are made by Ultimheat alliance members.

Fail safe is a positive auto control of the device. Any leakage or breakage of the temperature sensing device causes the electrical power shut-off. This function is difficult to define in bimetal thermostats (discs, rod, bimetal), but for thermostat using a bulb and capillary assembly, it defines the mode of operation when it leaks.

#### The fail-safe mechanisms in bulb and capillary thermostats



#### **Diastat Standard Operation:**

Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

Position1: a standard diastat is shown in the starting position, at room temperature.

In position 2: the temperature of the sensor has reached the set point, and the inflation of the bellows caused the opening of the contact, stopping heating.

In position 3: the bulb (or capillary) leaks, the bellows deflates, the electrical contact closes, and the heating is switched on again. But no further expansion is transmitted to the bellows, and nothing can stop nor regulate heating. This is the dangerous situation that failsafe systems must obviate.

Positive safety is primarily used on manual reset thermostat, installed after a standard temperature control unit.

There are two fail safe systems with a different mode of operation, each system having its own advantages and disadvantages.

#### Liquid expansion type failsafe systems



In these systems, after sealing the diastat at ambient temperature, a small bump is made on the bulb, causing an artificial inflation of the bellows (1). It is also possible to produce the same function by sealing the diastat at a negative temperature (-20, -30 ° C). By these ways the bellows continues to contract at temperatures below room temperature.

When the temperature on the bulb increases (2), the movable part of the electrical contact is actuated by the bellows. When the bulb or the capillary is leaking (3) the bellows is deflated under the thickness it has at ambient temperature, and an auxiliary mechanism (in red) displaces the fixed part of electrical contact out of reach of the movable part, thereby opening the contact. This positive safety system allows easy adjustment of the thermostats trigger temperature, because the mechanism is similar to an adjustable thermostat, and calibration can therefore cover the entire temperature range of these adjustable thermostats. However, it has two issues:

• The artificial increase of the bellows significantly increases the volume of liquid inside thereof, and thus increases its sensitivity to the ambient temperature on the thermostat head.

#### Examples of calibration point drift on a manual reset thermostat with 1.5 m capillary, calibrated at 90 ° C

Type of mechanism	Set point drift with head temperature at 0°C	Set point drift with head temperature at 50°C
With fail safe	90+8,1	90-9.5
Without fail safe	90+5,5	90-6,5

• When the ambient temperature falls under the freezing point, the bellows continues to contract, and can unexpectedly actuate the safety.

This type of false tripping is supervised by the EN60730 standard, which sets the minimum ambient temperature without triggering at -15 ° C.

However, when using these thermostats in areas with ambient temperature lower than this limit, it is necessary to warm up the thermostat bulb around 20 ° C to reset the safety when it has triggered.



#### **Boiling style failsafe systems**



#### In boiling type fail safe systems, the bellows of the diastat consists of two dishes, one of which is bumped.

This bumping is of convex shape, as a bimetallic disc, and snaps from convex to concave when subjected to a force. The diastat, before filling (1) is constructed so that the cup is in the unstressed position is outwardly bulged.

The diastat is then filled with thermostatic liquid under vacuum, then sealed with the cup pushed inwards (2). In this position, the electrical contacts are closed.

Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

In case of temperature rise, the liquid boils at the temperature determined by its composition. The substantial increase in volume caused by the boiling causes the change of shape of the cup, which snaps outwards and opens the contact (3). Upon cooling of the liquid, the force produced by the diastat and required for bumping inwards the cup is insufficient, and it is necessary to press it with a reset button to restore it to its inward form.

In case of punctures or leaks in the diastat, the liquid inside is set to the atmospheric pressure, and the cup snaps outwardly. This system is particularly simple, reliable, and requires no complicated mechanism. It is not sensitive to the ambient temperature on the capillary or on the head, does not trigger unexpectedly when ambient temperatures are too low. It has, however, like the previous one, two flaws:

• Triggering temperature depends of boiling liquid used (Generally mixtures of water, glycol and alcohol), and therefore they are practically limited to values between 60 and 170 °C.

• They are sensitive to atmospheric pressure and set point varies slightly with altitude.



#### **2.5 MULTIPLES CONTACTS**

#### 2.5.1 CHANGE OVER CONTACTS (SPDT, for: single pole double throw)

The changeover contact is a contact with three terminals. They are a common, a normally closed contact and a normally open contact. During actuation, the contact switches from one position to another. This allows for example to switch off the heating and simultaneously turning on ventilation

#### **2.5.2 SIMULTANEOUS CONTACTS**

Simultaneous contacts are independent contacts, with synchronous action.

This is particularly important in cutting a three-phase circuit devices, because the cut of the three phases must be done at the same time

#### **2.5.3 STAGGERED CONTACTS**

can be modified without prior advice

rand (

guidance only

on these data sheets are for

features used

descriptions,

drawin

products.

Because of permanent improvement of our

These contacts are operated by the same measuring system, but at different temperatures.

#### **2.5.4 NEUTRAL ZONE CONTACTS**

These contacts are parts of the staggered contacts, but with no electrical action between their set points. Their particular application is the air conditioning or refrigeration.

For example the contact # 1 switches off the heating at 100 ° C, the contact # 2 will turn on the vent at 120 ° C. Between these two temperatures, no action will be required: this is the neutral zone

#### 2.5.5 ADJUSTABLE DIFFERENTIAL CONTACTS

The differential is the temperature difference existing between the moment the device actuates (opens) a contact and when, as a result of the drop in temperature resulting from its opening action, it resets.

Depending on the type of contact, these differentials can have huge span.

The adjustable differential is a system that allow the user to change it.

For technical reasons and cost, adjustable differential mechanism is reserved for industrial type systems using gas expansion.

#### 2.5.6 MIXED CONTACTS

Mixed contacts by means of a combination of different systems above.

The most common combination is a control and a reset contact, or or a control and a one shot contact.

#### 2.5.7 FLAMEPROOF CONTACTS

A flameproof contact is a contact does not allow the electric arc that it produces to ignite an explosion outside its enclosure. The electrical arc is not deleted.

There is a difference between the devices whose only the electrical contact is protected and those whose entire mechanism is protected.

#### 2.5.8 FLAMEPROOF ENCLOSURE CONTACTS

In these devices only the mechanism of the electrical contact is protected by a flameproof enclosure. The electrical connections are made at the end of a cable secured to the casing of the contact area and must be made outside the hazardous area, or in a suitable connection box.

This solution provides small devices, and low cost.

#### **2.5.9 FLAMEPROOF ENCLOSURES**

Flameproof enclosures are massive envelopes where the entire device is enclosed. Electrical connections can be made inside the envelope.

#### **3. THERMOSTATS TYPES**

#### **3.1 BIMETAL THERMOSTATS**

It is currently the thermostats family where quantities are the most important. Numerous configurations exist, and the current trend is simplification and footprint reduction.









## Introduction to thermostats technology

#### **3.1.1 FIXED TEMPERATURE BIMETAL THERMOSTATS**









Fixed temperature bimetals thermostats are devices whose temperatures are factory fixed, and which have no set point access by the user. They are used, depending on the model, as control devices or safety. The contacts can be slow make or break or snap action, control or reset, normally open, normally close or SPDT. Almost all contact options described above are possible. These devices are divided in two major groups: those sensitive to the current (which are smaller) and those insensitive to the current.

The most common ranges are set from 20 to 180 °C.

However, models with ceramic case can be made up to 450 °C, and waterproof models to -30 °C

#### **3.1.2 ADJUSTABLE BIMETAL THERMOSTATS**

They are adjustable by screwdriver or shaft. Their main applications are in small appliances (deep fryers, irons).

They are always control type devices, using a bimetal strip.

Common temperature ranges are from 20 to 300 ° C.

**3.2 BIMETALLIC EXPANSION THERMOSTATS** 

They are current sensitive or insensitive depending on models.

Models with current sensitive bimetal or heated by a resistance, are used in energy regulators.

#### **3.1.3 SPIRAL BIMETAL THERMOSTATS**

Bimetallic spirals have been widely used for the production of thermostats. This system is now abandoned by European manufacturers, as it required using a mercury bulb contact, or a slow break contact. There are still only a few manufacturers in the USA, for 110V applications. These bimetallic spirals (helicoil style) are still used in some air duct thermostats (Called airstats).



Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice



#### **3.2.2 CONTACT THERMOSTATS**

20 to 300 ° C.

These control devices, adjustable, slow break, have a very high precision, and low differential: less than 1 °C. They are mounted on a flat wall, fixed by 2 screws.

However, because of their slow break, generating radio interferences in 230V, their use in Europe is marginal, restricted to uses in some laboratory hotplates or when low differential are sought. Common temperature ranges are from 20 to 250 °C.

**3.2.1 CARTRIDGE THERMOSTATS** 

mounted in a 15.8mm dia. bore.

These control devices, adjustables, slow break, have a very high precision, and the lowest possible differential for a mechanical thermostat: less than 1/10 °C. In general, they are

However, because of their slow break, generating radio interferences in 230V, their use in Europe is marginal, restricted to uses in some laboratory hotplates. Common temperature ranges are from



#### **3.2.3 BIMETAL ROD THERMOSTATS**









It is currently the main application of bimetallic systems. The bimetallic rod actuates a contact system. The setting can be fixed or with a graduated knob. The contacts are control, manual reset or mixed types. The main applications are:

• Household storage water heaters. They are controlled by a screwdriver adjustment, with single-pole switching thermostat for temperature control, with temperature sensing made by the rod, and double pole switching for the manual reset, with temperature sensing usually made by a bimetal disc located at the bottom of the tank. They are protected by the cover mounted under the water heater.

• In water heaters and industrial tanks. The temperature control devices are then split: one for control and one for safety. They are mounted in IP65waterproof housings.

• In hydraulic systems, where they are use for oil temperature control. They have 1,2 or 3 staggered contacts to provide different levels of alert and security.

Current temperature ranges span from -50 to 400 °C. However, some special models can reach 800 °.

#### **3.3 LIQUID EXPANSION THERMOSTATS**

#### **3.3.1 MERCURY EXPANSION IN GLASS TUBE**

This is one of the first thermostat systems, invented after the mercury thermometers. A wire is inserted in the capillary glass tube. When the mercury

touches the wire, the contact is established. This type of thermometer has long been the reference instrument for precise temperature control. It has no more serial applications.

#### **3.3.2 BULB AND CAPILLARY THERMOSTAT**



Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice







This is the most common remote measurement and temperature control. The capillary lengths can be up to 3 meters but with a significant drift due to the amount of liquid within the capillary.

In this series, fail safe devices may be produced. Current ranges of temperature span from -50 ° C to 400 ° C, exceptionally up to 760 ° C.





#### **3.3.3 LIQUID FILLED ROD THERMOSTATS**

This family is a variant of the bimetal expansion rod thermostat. It differs by a greater resistance to vibration but a longer response time. Applications are identical. Current ranges of temperature ranging from -50  $^\circ$  C to 400 ° C, exceptionally up to 760 ° C.

#### **3.3.4 PIPE THERMOSTATS**

These thermostats use a bulb and capillary mechanism, thermostat but with a very short capillary and a bulb beneath the housing on a pipe radius formed plate. The housing has a system for fixing the plate on a pipe.

Usual setting of these control these devices are between 0 and 120°C.

#### **3.3.5 ROOM THERMOSTATS**

These thermostats use a bulb and capillary mechanism but with a very short capillary and a bulb located at the side or at the back of the housing. This system is particularly useful for professional and industrial equipment. Current ranges of temperature span from -40 ° C to 120 ° C.

#### **3.4. GAS EXPANSION AND VAPOR PRESSURE THERMOSTATS**

#### **3.4.1 BULB AND CAPILLARY ROOM THERMOSTAT**

These vapor pressure devices are mainly used in electric convector thermostats, due to their low differential and low thermal inertia. Current temperature range: 4 to 40 ° C.

#### 3.4.2 « WAFER » ROOM THERMOSTATS

It is currently derived from incubator thermostats used in poultry incubators since more than 50 years. The sensitive part is a barometric type capsule (Named 'capsule de Vidie'), filled with low boiling temperature liquid. They are widely used in household room thermostats. Current Page: 4 to 40 ° C

#### **3.4.3 CAPILLARY THERMOSTATS**

These thermostats are used for controlling the temperature of the refrigerating systems. The low thermal inertia of the capillary system, and the possibility of obtaining significant differential is the main feature of these vapor pressure devices.



secause of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice











비린ㄹ











#### 3.4.4. BULB AND CAPILLARY THERMOSTATS

They are mainly used in industrial applications because the vapor pressure can achieve quite easily adjustable differential devices.

#### **3.4.5 AIR DISPLACEMENT THERMOSTATS**

These devices were using a filament style heating system in a glass bulb partially filled with air and containing mercury. Pushed by the expanding air, the mercury passed through a tube into a compartment containing an electrode with which it established an electrical contact. This system, coupled with a slow break bimetal thermostat contact avoided contact triggering, and achieved very low differential and high electrical rating. This system ,very accurate, very reliable, has completely disappeared.

#### **3.4.6 THERMOMETERS**

The gas expansion thermometers are used in industrial applications, they have a low thermal inertia and can be used in high temperatures.

#### **3.5 PHYSICAL STATE CHANGE THERMOSTATS**

#### 3.5.1 "CALORSTATS"

features used on these data sheets are for guidance only and can be modified without prior advice

descriptions,

products, drawings,

our

Because of permanent improvement of

They use the wax melting temperature expansion. There is little use of them in systems operating an electrical contact, but they are widely used to provide mechanical movements (Car engine thermostats, radiator thermostats, door locks, valve control). This system can actuate an electrical contact, or operate a valve to control the flow of water when the temperature changes.

Current ranges from 30 to 150 ° C.

#### **3.5.2 THERMAL FUSES**

This is the main system used in thermal cut out. Millions of these devices are currently produced in the world. It is a highly reliable system, whose operation is safe. The electrical contacts are either cut by the conductor melting (Rating generally limited to 4A) or by melting of a pellet releasing a spring contact (Rating up to 25A).

Current ranges from 60 to 300 ° C.

The melting part is made of metal or plastic.

This system, known as TCO (thermal cut-off ) is the ultimate security system. It is inexpensive.

A variant of these systems are also used in non-electric appliances for releasing a mechanism, in particular in fire detection apparatus.

#### **3.5.3 BOILING THERMOSTATS**

The most common thermostat of this type is the failsafe capillary limiter with manual reset.

This system measures the boiling of a liquid contained in a capillary or a bulb at the end of the capillary. Temperature sensing on + / -300 mm capillary is required to operate the contact. For this reason, models often have their capillary curled at the end, with dimensions similar to a bulb. These devices are always fixed temperature types, most of time calibrated within the 50 to 170 °C span, and the capillary length is limited to + / -900 mm for transmission of the excess pressure due to the boiling reasons or depression due to the rupture of the capillary.











#### 4. APPLICATIONS

Principle	Family	Sub family	Application
	Fixed setting	Current sensitives	Coils protectors, small appliances, auto- motive, rechargeable batteries
Co-laminated bimetals	Fixed setting	Non sensitives to current	Small appliances, HVAC, refrigeration equipment
	Adjustable setting		Irons, grills, crêpes makers
	Spiral		Thermometers, airstats
	Cartridges Surface sensing		Heating plates, flat heaters, medical equipment
		For incorporation	Household water heaters
Double metals	Ded	Professionnals	HVAC
	Rod	Industrials	Tanks, Hydraulic power units, heaters
		Explosion proof	Chemical industry
	Glass	Laboratory	Various
	Bulb and capillary for incorporation	Appliances OEM	Ovens, cookers, washing machines, dish- washers, boilers
Liquid expansion	Bulb and capillary with metal protection housing	Semi-professionnel	OEMs electro, kilns, ovens, air heaters
	Bulbe et capillaire s/s boîtier	Industrial and/ or hazardous area, heavy construction	Factories, maintenance, heat tracing
	Bulb and capillary		Electric heaters, refrigerators thermostats
Vapor pressure	Membrane		Household room thermostats
	Air displacement		No more used
	Wax		Automotive, hot water central heating
		Conductor melting	Small appliance, coils, batteries, electronic
Physical state change	Compounds melting	Pellet melting	Household appliances, electric heating, motors
	Boiling	Capillary	Heaters, electric air heaters, heat pumps
		Glass bulb	Air conditionning, fire detection

Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice



#### 5. Terminology and vocabulary

## Standards EN60730 and EN 60335 define, sometimes with differences, the vocabulary to use. However, it is often different from that used in practice.

#### Usual vocabulary:

be modified

g

and

guidance only

đ

are

used

Sel

drawings,

products,

OUL

Ъ

mprovement

permanent

Set point: The value set on the temperature control device, corresponding to the temperature to reach

*Differential:* the temperature difference between the opening and closing of the contact

Snap action: contacts open and close instantly

*Manual reset:* action to turn on by manual intervention, to heating position contacts opened by a temperature rise that did not automatically return to closed position when the temperature drops

Automatic reset: Contact that is automatically closed when the temperature drops

Sensing control: automatic control in which initiation is by an element sensitive to the activating temperature

#### Definitions of the different thermostatic systems according to EN60335-1

§3.7.1 Thermostat: temperature sensing system of which the operating temperature may be fixed or adjustable and which, during normal operation, maintains the temperature of the controlled part within certain limits by automatic opening and closing of a circuit

§3.7.2 temperature limiter: temperature-sensing device, the operating temperature of which may be either fixed or adjustable and which during normal operation operates by opening or closing a circuit when the temperature of the controlled part reaches a predetermined value

NOTE A temperature limiter does not make the reverse operation during the normal duty cycle of the appliance. It may or may not require manual resetting.

temperature limiter: temperature sensing control which is intended to keep a temperature below or above one particular value during normal operating conditions and which may have provision for setting by the user

A temperature limiter may be of the automatic or of the manual reset type. It does not make the reverse operation during the normal duty cycle of the appliance.

§3.7.3 Thermal cut-out : device which during abnormal operation limits the temperature of the controlled part by automatically opening the circuit,... and is constructed so that its setting cannot be altered by the user.

thermal cut-out: temperature sensing control intended to keep a temperature below or above one particular value during abnormal operating conditions and which has no provision for setting by the user

A thermal cut-out may be of the automatic, manual reset or non-resettable type.

§3.7.4 self-resetting thermal cut-out: thermal cut-out that automatically restores the current after the relevant part of the appliance has cooled down sufficiently

§3.7.5 non-self-resetting thermal cut-out: thermal cut-out that requires a manual operation for resetting, or replacement of a part, in order to restore the current

NOTE Manual operation includes disconnection of the appliance from the supply mains.

§3.7.6 Protective device: device, the operation of which prevents a hazardous situation under abnormal operation conditions §3.7.7 Thermal link: thermal cut-out which operates only once and requires partial or complete replacement

**Fail safe temperature limiter:** the fail safe in a thermostat is defined by the EN60730-2-9 Standard § 6.4.3.101, as a temperature control device wherein a leakage of the filling fluid does not increase the temperature set point. More generally a system is said to be failsafe, when a loss of fluid (including electricity) leads the equipment to a stable safety state. The safety state must be maintained over time.

#### Thermostats recommended applications:

IEC (EN) 60730-1 Standards « Automatic electrical controls

for household and similar use» and especially IEC (EN)

60730-2-9-(2008) : « Particular requirements for temperature sensing controls» are the standards that define the functional characteristics of thermostats. Appendix EE of the latest version of the standard describes all recommended applications for these devices.

#### 5.2 COMMON VOCABULARY USED TO DESIGNATE A THERMOSTAT

Dozens of names are used by the customer to designate thermostats. We can mention:

aquastat, airstat, bimetal sensor, temperature sensor, temperature switch, temperature detector, thermal sensor, thermal switch, temperature limiter, thermal pellet, pellet thermostat, thermal protector, temperature controller, sensor, temperature probe, temperature sensor, thermostat

Some brands have passed into the vocabulary:

Klixon: Texas trademark instrument means a bimetal disc thermostat.

Combistat: Stork trademark refers to a contact thermometer

Vigitherme: Heito trademark refers to a thermostat bimetal disc.

Ipsotherm: Comepa trademark refers to a thermostat bimetal disc.

Calorstat: brand used by Vernet thermostat, refers to an automotive water circuit valve.



#### 6. Important extracts of standards related to control or safety circuits

#### Electrical cut out: (IEC 60335-1)

**§3.8.1 All-pole cut out:** Cutting in two conductors in a single operation, or for three phase units, the cut of the three conductors in a single step ... Note: for three-phase, the neutral lead is not considered as a power conductor.

§22.2: Phase cut out: single pole protection systems cutting heating elements in single pole circuits of Class 01 devices and continuously connected Class 01 devices, must be connected to the phase conductor.

#### Electrical conductors colors: (IEC 60446)

§3.1 ... For the identification of leads the following colors are allowed: black, brown, red, orange, yellow, green, blue, purple, gray, white, pink, turquoise.

§3.2.2 Neutral conductor or center conductor : when a circuit includes a neutral conductor or neutral conductor identified by color, the color used for this purpose should be blue ...

Note 2 – In the United States of America, Canada and Japan, identifying with white or natural gray colors for the neutral conductor or center conductor is used as a replacement for the identification by the light blue color.

§3.2.3 AC phase conductors: black and brown colors are the favorite colors for the phase conductors of AC systems.

**§3.3.2** Conductor protection: The two-tone green-and-yellow combination must be used for identification of the protective conductor to the exclusion of any other use. The green-and-yellow is the only recognized color scheme for the identification of the protective conductor

Note 2 – In the United States of America, Canada and Japan, identifying with green color for the protection conductor is used as a replacement for the identification by the two-tone green-and-yellow combination.

on these data sheets are for guidance only and can be modified without prior advice

Because of permanent improvement of our products, drawings, descriptions, features used

#### Fail safe, functional safety, safety levels:

It is required by the European Directive 97/23 dealing with heat generators, pressure equipment and boilers as follow: «the procedures for conformity assessment and the essential safety requirements of the Directive apply to the complete safety chain. The requirements for the sensor itself can be different according to the safety design principles, for instance: redundancy or fail-safe ». Many "product" standards of the IEC (EN) 60335-xxx series require this type of safety.

Definitions related to the functional safety: this concept was introduced by the CEI 61508:1998 Standard. « Functional Safety for electrical /electronic and programmable electronic (E/E/PES) systems». This standard defines the requirements and provisions for the design of electronic and programmable complex systems and subsystems. This is a general standard that can be used in all industrial sectors. The categories of protection of industrial heating equipment have been classified into three levels by the old EN 954-1 Standard.

Level 1 includes mainly the process control instrumentation: temperature sensors, thermostats, controllers, programmers. This level provides a control either permanently or in a sequence by programmed commands initiated by the operator (for example: control disc, bimetal, bulb and capillary thermostats, electronic temperature controls).

Level 2 consists essentially of an instrumentation composition close to that of level one, but functionally completely independent of this level.

This level 2 protects the process by a discontinuous unsystematic function, that is to say not initialized by the operator, from threshold violation information on critical parameters of the process.

(For example, disc thermostat + disk limiter, bulb and capillary temperature limiters + bulb and capillary thermostat, double electronic controllers)

Level 3 is the ultimate protection of the process. It does not include identical instrumentation to those of Level 1 and 2, but devices working without auxiliary energy (for example: fixed temperature limiters with manual or automatic reset on circuits controlled by electronic controllers, thermal fuses for systems controlled by disc or bulb and capillary thermostats, or by electronic controllers).



#### 7. INSTALLATION

The proper functioning of a thermostat depends primarily on the correct choice of the component, but also the conditions of its installation. Conditions used to calibrate regulating and control equipment in the factory are always ideal laboratory conditions, ensuring measurement accuracy and repeatability. These conditions are rarely those found in practice when installing thermostats. However, with a minimum of constraints, it is possible to optimize assemblies.

One's will always bear in mind these two essential rules:

• A thermostat measures the temperature where the sensing element is located, and it is therefore necessary that this place is representative of the temperature that must be controlled.

• The thermal inertia is the most common causes of poor regulation. A thermostat does not have an instant response to a temperature change.

#### 7.1 GENERAL RULES

#### THERMAL CONDUCTIVITY

The temperature of a medium (liquid, air, metal) decreases progressively as the distance from the heat source. This decrease, called thermal gradient is inversely proportional to the thermal conductivity of the medium. For good temperature control, first step is to make this decrease as low as possible: by stirring the liquid, stirring the air, using metals that are good conductors of heat.

In unstirred liquid baths, thermal variations that rise several tens of degrees between different measurement points are quite common. It is the same in the air.

#### RESPONSE TIME

can be modified without prior advice

oermanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and

Practically speaking, the time taken by a device to change temperature is proportional to its mass and inversely proportional to its thermal conductivity.

Subject to the same variation of temperature, a large block of copper takes longer to heat up than a little. A block of pure silver of the same weight will react much more quickly.

In one room, sun exposure will raise rapidly the temperature of the ambient air because its mass is low, but the walls will react much more slowly because they are much more massive, even if their thermal conductivity is higher. Therefore, to control the air conditioner, make sure that the thermostat measure the temperature of the air and not of the walls.

ومحمد ومحمد والمحمد المناطقة والمحمد و

	Thermal conductivit	ly of some materials	
Materials	Thermal conductivity at 20°C (W•m-1•K-1)	Materials	Thermal conductivity at 20°C (W•m-1•K-1)
PU foam	0,025	Titanium	20
Ait (atmospheric pressure)	0,026	304 Stainlss steel	26
EPS	0,036	Mild steel	46
Fiber glass wool	0,043	Platinium	72
Cork	0,043	Iron	80
Wood (Average)	0,16	Cast iron	100
Abestos	0,17	Silicium	149
Ероху	0,25	Aluminum alloy (with SiC)	150-200
Nylon	0,25	Pure aluminum (99.9%)	237
PPS (Ryton)	0,3	Massive silicium carbide	250
Vulcanized rubber (EPDM)	0,4	Gold	317
Water	0,63	Copper	390
Concrete	0,92	Silver	429
Glass	1,23	Graphite	500-2000
Bakelite	1,42	Diamond	1000-2600
Quartz	10	Graphene	4000-5300

It is easily possible to see that if a thermal gradient takes 1 second to be transmitted in a silver part, it will take 1.1 seconds in copper, 2.5 seconds in aluminum alloy, 4.3 seconds in iron, 6.3 seconds in mild steel, 16.5 seconds in stainless steel, 680 seconds (more than 11 minutes) in non-stirred water and 16500 seconds (more than 4 hours) in still air.

#### TIME NEEDED TO HEAT

An issue frequently raised, and that many consider as associated with thermostats is the time it takes to heat a product. In fact, at constant power, the amount of heat (energy) required to heat a product depends on its mass and its heat capacity, and not on the thermostat.

Specific Heat capacity (or specific thermal capacity) is the energy it takes to bring a body to raise its temperature by one degree kelvin for a mass of one kilogram. It is expressed in joules per kelvin per kilogram (J / K). It originates from the "calorie" that was defined as the amount of heat required to raise 15 °C to 16 °C the temperature of one gram of water. The table below gives some common values

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr



Materials	Specific heat capacity (J*kg-1*K-1)	Materials	Specific heat capacity (J*kg-1*K-1)
Gold	129	Granite	800
Silver	240	Concrete	880
Brass	377	Alunimum	897
Copper	385	Dry Air	1005
Iron	444	Wood	1760
Diamond	502	Olive oil	2000
304 Stainless steel	510	Alcohol	2450
Graphite	720	Liquid water	4180
	1 1 600 1		

One can easily notice that the same power, whether 600 seconds are needed to heat one kilogram of water, it will take only 290S for oil, 145s for air, 73s for stainless steel, 55s for copper, and 18s for gold. The heat capacity is an extremely important parameter in the definition of a thermal system.

#### • OVERHEAT AND HEAT ACCUMULATION

Many heating systems accumulate heat before transmitting it to the environment.

This is especially the case with sheathed heating elements, where heating wires are coated with magnesia, and then covered with stainless steel tube. Before the stainless steel sheath begins to warm, the entire interior of the heating elements has heated up.

When the power is then turned off, the heat accumulated inside will continue to dissipate, and the temperature of the outer shell will continue to rise. A temperature control which regulate by measuring the temperature of the outer shell will be false.

#### 7.2 WALL AND PIPE MOUNTING THERMOSTATS

These thermostats are intended to be mounted on walls. This covers bimetal disc thermostats, with or without bracket, and pipe formed models.

The following requirements must be respected:

• In the case of thermostats with a flat sensitive part, the mounting wall must be flat. In particular, if it is needed to measure the temperature of a small diameter tube, it is mandatory to weld or solder a heat conductive part made of copper or brass on the tube surface, with a flat surface on the side facing the thermostat.

• In the case of thermostats whose sensitive part is curved to match the shape of the wall (tanks, pipes): use thermal contact grease between the thermostat sensing face and the wall, insulate the thermostat body to limit the influence of the ambient temperature, have in mind that the whole thermostat must withstand the maximum or minimum temperature of the wall. Check if these temperatures are compatible.

#### 7.3 AIR DUCTS THERMOSTATS

Thermostats must be installed in an area where there is good air circulation. Avoid corners, angles. The thermostat should be located close to the heating element (or cooling) to be quickly influenced by temperature changes. The extended bracket disc thermostats must be mounted on a wall that is not influenced by a temperature other than that of the air stream.

Attention to the use of bimetallic rod thermostats in air ducts: These devices generally have very fast response time to temperature changes, and some models are not suitable for use as safety device because they trigger too fast.

#### 7.4 ROD THERMOSTATS

Rod thermostats should be mounted on fittings provided for this purpose. The rod cannot be bended, welded, soldered, and no external device must hinder the rod expansion.

The whole sensitive part of the rod must be immersed in the air or liquid that it must control.

Do not mount the thermostat on a stack of fittings and rod must be in an area representative of the temperature of the tank. Avoid areas without natural convection or no stirring.

Whatever the installation, the thermostat head must not exceed the maximum allowable temperature. In particular, when mounting thermostats on high temperature equipment, the head must be kept away from hot walls.

Use pockets adapted to the rod diameter, and do not hinder expansion movements. If you want to get accurate settings and low differential, put thermal grease between the pocket and the rod.

#### 7.5 BULB AND CAPILLARY THERMOSTATS

The bulb and capillary thermostats are provided to measure the temperature with the bulb located inside the medium to control. However, the capillary and the rest of the diastat are influenced moderately by temperature. It is therefore important not to expose them to temperatures too high, and in particular never exceed the maximum allowable temperature of the thermostat head. Capillaries and in particular capillary junctions with bulb are fragile and care must be taken not to bend capillaries with a radius smaller than 5 mm, or near the bulb. Breakage or leak of the capillary after sharp bending voids any warranty on the equipment. Overheating bulbs or capillaries on liquid expansion models cause unwanted boiling of the liquid and the destruction of the thermostat. Cutting or drilling capillary or bulb destroys the mechanism, and the thermostat does not stop heating when the temperature rises, If this risk is important in your application, be sure to use failsafe thermostats.

#### 7.6 WINDINGS THERMOSTATS

Windings protectors must be installed to measure the fastest way the temperature rise of the winding. They must not be bended or distorted during installation inside the coil. Before to be incorporated into windings that must later be impregnated by resin or varnish, ensure that these thermostats support these operations. Our office is at your disposal to give you technical advice. Calibration temperatures warning: thermal protectors are calibrated at zero current and their operating temperature is sensitive to current. In your application, depending on the current rating of your device, their set point can be shifted down. Use thermostats drift curves to define thermal drift temperatures. Many thermal protectors have metal enclosures electrically alive. Be sure to install them safely, with proper electrical insulation and not in contact with grounded or accessible parts. For these devices, class 1 and class 2 electrical insulation sleeves can be provided on request.

#### 7.7 THERMAL CUT OUT

be modified without prior advice

g

rand c

on these data sheets are for guidance only

features used

Because of permanent improvement of our products, drawings, descriptions,

Thermal fuses are the components the most susceptible to wrong installations.

Their terminals are heat conductors: welding or soldering them can cause the fuse to open by thermal conductivity.

Do not make soldering at less than 15mm of the housing. The soldering duration shall not exceed 3 seconds. Terminals wires are also sensitive to strength and torsion. Be careful not to apply significant forces (1.3 N max).

Bending terminal wires should be preferably made with a wire bending machine. Do not bend or crimp at less than 5mm from the body. Do not crush the body.

Sensitivity to temperature: thermal fuses must not remain continuously exposed to temperatures that are too close to their cutoff temperature. Respect the maximum allowed permanent temperature given in technical data sheets. They are also sensitive to current and can trigger by Joule effect if the rating is too high.

#### 7.8 VAPOR PRESSURE BULB AND CAPILLARY THEMOSTATS

These thermostats are particularly sensitive to the position of the capillary or of the bulb relative to the thermostat head. Observe the position indicated on the data sheets for each device.

#### 7.9 EXPLOSION PROOF THERMOSTATS

The explosion-proof devices require special care during assembly. A specific mounting and assembly instruction manual is supplied with each unit.

• Explosion-proof enclosures: These housings are designed to withstand an explosion occurring within the housing. It is therefore important to take particular care that the screws of the cover (these screws cannot be replaced by others models with different mechanical resistance), to ensure the cleanliness of the sealing surfaces, not drill holes in the boxes, not to replace original cable glands by others, properly tighten the cable glands, ensuring that their gasket is adapted to the diameter of the cable used.

• Explosion proof Switches: In thermostats using this system, only the electrical part of the switch mechanism is enclosed in a flameproof enclosure. By this way, the outer casing of the thermostat does not provide explosion protection, but only requires at least IP65 ingress protection. Electrical connections must be made on the cable coming out of the unit, outside the hazardous area or in a suitable junction box.





#### Disc thermostats

Used as control thermostats or as a safety thermostat with manual reset, these thermostats have a disc made of two different metals laminated together for temperature sensing element. These two metals have different expansion coefficients. Therefore a dome bumped disc will gradually change shapes with increasing temperature until it suddenly snaps from concave to convex. It also comes back with a snap action to its original form when temperature drops. This sudden change activates a contact blade. These thermostats exist with one, two or three pole contacts. Technology to obtain accurate temperatures and low differentials is complex and few manufacturers offer accurate values and low differentials. JPC is one of the very few manufacturers offering three poles models.

#### Surface mounting Bimetal strip thermostats

These control devices, adjustable, slow break, have a very high precision, and low differential: less than 1 ° C. They are mounted on a flat wall, fixed by 2 screws However, due to their slow break, generating 230 parasites, their use in Europe is marginal, limited to laboratory uses or when low differential are sought. Common temperature ranges are from 20 to 250 ° C.



#### **Energy regulators**

The energy regulators are a type of thermostat bimetal having a heating resistor in contact with this miniature blade. The power of this internal resistance heats the blade, which is deformed and cuts off the supply of the resistance. The blade is then cooled and the contact closes and a new cycle begins, like a flash. The setting pin to change the ratio between the time of opening and closing, and provides the electrical connection to an external load in parallel with the internal resistance. This simple system allows you to adjust continuously the resulting power a heater. The power supply circuit must be specified as the miniature internal heater is made in terms of this tension.

#### **Bulb and capillary control thermostats**

Bulb and capillary thermostats sensing device, usually named "Diastat" is a closed chamber made of a bulb, a capillary and a bellow made of two membranes, filled under vacuum with liquid. When temperature around the bulb increases, the liquid volume expands and inflates the membrane. This displacement is used to actuate a snap-action switch mechanism. A threaded shaft, used to modify the bellow position allows temperature adjustments. In standard devices (not fail safe), when a leak occurs in the Diastat, the bellow deflates and electrical contacts remains closed when the temperature rises. The most common ranges go from -35 to +320°C. Higher set points up to 750°C are possible but they require capillary liquids that withstand these temperatures without boiling. JPC is one the very few companies manufacturing these models. These high temperature versions (ranges above 400 °C) use a liquid metal as filling liquid, usually a Sodium Potassium eutectic. In case of breakage or leak of the Diastat, this liquid is flammable on contact with water or atmospheric moisture. It is therefore necessary to take this point into account in their applications.

The capillary thermostats are subject to drift due to temperature variations on the capillary and the bellows. The bulb and capillary thermostat differential is usually not adjustable, and is about 2.5% of the temperature range. They are available in single pole or three pole versions.

#### Invar Rod thermostats for temperature control

These thermostats are the oldest systems of temperature control, and the first of them was invented by French engineer Jean Simon Bonnemain in 1783. They use the differential expansion of two metals to activate a mechanism. They are widely used in storage water heaters and in boilers. Their calibration is not subject to ambient temperature variation drift such as liquid expansion bulb and capillary thermostats. They are available with control action or manual reset action. Their specificity is that the measuring rod is secured to the adjustment head and electrical contacts.

Current models, using a brass or stainless steel tube and invar rod, have measuring ranges between -50 and +400 ° C. JPC is currently the oldest French manufacturer of this type of thermostats.



#### Bulb and capillary thermostats with explosion proof electrical contacts

Built on the same mechanical basis than the standard thermostats, and achievable within the same temperature ranges, these thermostats use an explosion-proof micro switch which is a unique design concept developed by JPC. The advantage of this system is to avoid heavy and expensive IIB or IIC metal boxes, and to allow temperature set point adjustment without need to switch off the electrical power supply. The thermostat can be fitted in Y8 series standard waterproof enclosures, but its output cable connection must necessarily take place in an "increased safety" enclosure or outside the hazardous areas. The most recent versions include a built in increased safety enclosure. Depending of models, electrical rating can go from 5A 250V SPDT to 15A400V SPDT. 2 poles versions are also available





#### Liquid expansion bulb and capillary cut-outs with fixed temperature setting

These devices operate on a principle similar to the liquid expansion bulb and capillary thermostats and are not adjustable. They include a reset button to close the electrical contact when it has opened after a temperature rise.

There is one variant of these cut out, with a fail-safe mechanism. It automatically opens the contacts if the capillary or bulb are leaking or cut.

The Diastat membrane is artificially inflated. Leakage causes the bursting of the membrane below its nominal thickness at room temperature, and a special mechanism will detects the abnormal displacement, witch is similar to a very low ambient temperature sensing. The disadvantage of this system is that these fail-safe limiters also switch off when the ambient temperature drops below a certain value, generally between -10 and -20 °C.

The artificial inflation of the membrane also greatly increased the volume of liquid it contains, thus makes them highly sensitive to temperature, with temperature drifts up to 0.3  $^{\circ}$  K /  $^{\circ}$  K.

They can be used as an high limit safety device in addition to a mechanical thermostat or an electronic controller. They are available in single pole, two, three or four poles versions. They usually only have open on rise contacts.

#### Liquid expansion bulb and capillary cut-outs with adjustable set point

These devices operate on the same principle as the control thermostats, but feature a reset button to close the electrical contact when it opened after a temperature rise. They can be used as an overheating safety system behind a mechanical thermostat or an electronic controller. JPC is one of the few manufacturers offering this kind of thermostats with the same adjustment ranges than the control thermostats, and a change-over contact (which enables to signal a defect without relaying), and with ranges up to 750 °C.

#### Limiters bulb and capillary fixed temperature, vapor pressure (also called boiling)

These devices operate on a different principle than liquid expansion thermostat. They use a simple mechanism, invented 50 years ago by the Wilcolator company, combining the snap action of a bumped disc actuated by the huge pressure increase due to the boiling of liquid in a closed chamber. This design concept provides very simple mechanisms. Technology lies in the selection of liquids with different boiling points. Operating temperatures ranges are linked to the liquid used and its boiling temperature. Capillary length is also limited due to pressure losses induced during boiling, hindering its operation.

It is necessary that a relatively large volume of liquid is boiled to cause the membrane tripping. This is the reason why the capillary end measuring temperature is spiraled. If the capillaries are not spiraled, at least 30cm of it must be immersed in the controlled liquid. They are never adjustable and have a reset button to switch one the electrical contact when it is open as a result of an increase in temperature. As the filling is carried out under vacuum, a leak in the train thermostat triggers the mechanism. Unlike liquid filled systems sensitive to changes in temperature, they do not trigger when the temperature drops below a limit. However, they are slightly sensitive to changes in atmospheric pressure, which limits their use in altitude.

They can be used as a safety system of a mechanical thermostat behind overheating or an electronic controller. They are available with single pole, 2, 3 and 4 poles contacts. They usually have open on temperature rise contacts. Some models developed by JPC have SPDT and DPDT contacts

#### Invar Rod thermostats with manual reset

These thermostats are the oldest systems of temperature control, and the first of them was invented by French engineer Jean Simon Bonnemain in 1783. They use the differential expansion of two metals to activate a mechanism. They are widely used in storage water heaters and in boilers. Their calibration is not subject to ambient temperature variation drift such as liquid expansion bulb and capillary thermostats. They are available with control action or manual reset action. Their specificity is that the measuring rod is secured to the adjustment head and electrical contacts. Current models, using a brass or stainless steel tube and invar rod, have measuring ranges between -50 and +400 ° C. JPC is currently the oldest French manufacturer of this type of thermostats.











# Ex



#### Invar Rod thermostats with manual reset

These thermostats are the oldest systems of temperature control, and the first of them was invented by French engineer Jean Simon Bonnemain in 1783. They use the differential expansion of two metals to activate a mechanism. They are widely used in storage water heaters and in boilers. Their calibration is not subject to ambient temperature variation drift such as liquid expansion bulb and capillary thermostats. They are available with control action or manual reset action. Their specificity is that the measuring rod is secured to the adjustment head and electrical contacts. Current models, using a brass or stainless steel tube and invar rod, have measuring ranges between -50 and +400 ° C. JPC is currently the oldest French manufacturer of this type of thermostats.

#### Failsafe bulb and capillary cut out with explosion proof switch

Built on the same mechanical base than failsafe boiling cut out, and achievable within the same temperature ranges, these thermostats use an explosion proof switch. The advantage of this system is to avoid heavy and expensive IIB or IIC explosion proof housings. The thermostat output cable connection must necessarily take place in an "increased safety" enclosure or outside the hazardous areas. The most recent versions include a built in increased safety "e" enclosure. Depending of models, electrical rating can go from 5A 250V SPDT to 15A 400V SPDT. 2 poles versions are also available

#### Combined bulb and capillary thermostat / cut-out with adjustable set points

These devices operate on the same principle as the control thermostats, but feature a double bulb, one used for the control, the other for the manual reset. They have an adjustment shaft for the control, and a manual reset button allows switch on again the safety electrical contact, when it opened after a temperature rise. The safety set point is factory fixed. The contacts are open on temperature rise only. They are mainly used in three-phase applications, although there are SPNO and DPNO versions.

There are versions of these devices with failsafe manual reset contact, but they have a strong drift when the ambient temperature of the head varies, up to  $0.3 \degree C / \degree C$ . For example if there is a variation in ambient temperature of  $10 \degree C$  on the thermostat head, the set point drift can be as  $3 \degree C$ .





The thermal fuse cut-outs are composed of a contact mechanism triggered by melting of a metal or plastic pellet. They open irreversibly an electrical contact at a given temperature. Their trigger point should be selected according to the normal operating temperature and sufficiently distant from it to avoid false triggering. Their installation is hard to perform. JPC has developed a range of 16A 250V cut-offs which are wired and silicone insulated. They allow easy mounting in pockets.

#### **Blind electronic thermostats**

These products, developed by JPCI, provide a bridge between the electronic controls with digital display and the electromechanical thermostats of which they keep the setting ranges, mounting, current rating, on/off action, and with whom they are generally interchangeable. They are inexpensive, allow measurements at larger distances than the bulb and capillary thermostats. They provide a greater accuracy and the ability to adjust the contact differential.

#### **Electronic thermostats with digital display**

These products, developed by JFCI offer an easy to use electronic solution, with a digital display. From the electromechanical thermostats, they retain the electrical rating, the ON-OFF action, and ease of use.

They are inexpensive, and they allow, in addition to displaying the measured temperature, measurements at distances larger than the bulb and capillary thermostats, greater accuracy and the ability to adjust the differential temperature.

#### **DC** applications

For specific DC heating applications, mainly in railway systems, Ultimheat has developed contacts magnetic blowing devices. They can be applied to some models of thermostats (e.g.: disc thermostats, surface thermostat, bulb and capillary thermostats, rod thermostats), with electrical rating up to 230V DC and 16A, providing a long electrical life (exceeding 100,000 cycles). These developments are subject of specific studies on a case by case basis.



## **References table**

	· · · · · · · · · · · · · · · · · · ·	[]		·····				I []	
REFERENCE	PAGE	4911NP15023EL6VM37	38	66CP02	71	66MZ006-350352FW	53	IBJ2000632316002	41
66MZ0060000102FW	53	4911SU04511CL6HF39	38	66CP03	71	66MZ006-350352FX	43.47	IBK2000608313001	41
66MZ0060000102FX	53	4911SU04511CL6HM37	38	66CP04	71	66MZ006-350352FX	53	IBK2000608316002	41
1BA015095A200	50	4993AZ00805HCSV0	40	66DI12****	73	66RL14LB010	74	IBK2000632313001	41
1BA015095C300	50	4993AZ00805HL6H0	40	66DK12****	73	6Y4903RESET90	60	IBK2000632315302	41
1BA025165B200	50	4993AZ01006CL6MF	40	66DK12S190712	50.64	6YBUR001	71	IBK2000632316002	41
1BA-10130B200	50	4C504T070RMEM60D	61	66DK12S290712	50.64	6YEBMG002	74	KRA0000502000	44
1CA015095A200	50	4C504T075RMEM60D	61	66DL14P****	73	820060090CA61001	63	KRA0000701200	44
1CA015095C300	50	4C504T080RMEM60D	61	66DR12510021C000	73	820060090Cl61001	63	KRA0000705200	44
1CA015055C300	50	4C504T085RMEM60D	61	66DU****	73	820070100Cl61001	63	KRA0101501000	44
		4C504T090RMEM60D	61	66EL****	71	820080110Cl61001	63	KRA0101505000	44
1CA-10130B200	50	4C504T095RMEM60D		66EM****	71	820090120Cl61001		KRA0101505000	44
1DA015095A200	64		61				63		
1DA015095C300	64	4C504T100RMEM60D	61	66EN1	43,44,47,53,57,71	820110140Cl61001	63	KRA0104509000	44
1DA025165B200	64	4C504T105RMEM60D	61	66EN2	43,44,47,53,57,71	820130160Cl61001	63	KRA0200901000	44
1DA-10130B200	64	4C504T110RMEM60D	61	66EN3	43,44,47,53,57,71	820150180Cl61001	63	KRA0200905000	44
1RA015095A200	50	4C504T120RMEM60D	61	66GA2890K	0	820170200Cl61001	63	KRA0503000100	44
1RA015095C300	50	4C504T130RMEM60D	61	66GA2890K	71	8CB004040AA60001	47	KRA0605007000	44
1RA025165B200	50	4C504T140RMEM60D	61	66K***	71	8CB004040AO60001	47	KRA0605009000	44
1RA-10130B200	50	4C504T150RMGM60D	61	66MA	69	8CB030090AO60001	47	KRA0802000100	44
1UA015095A200	50	4C504T160RMEM60D	61	66MB	69	8CB030110AO60001	47	KRA-100152200	44
		4N630101308JGCD0	37	66MB060000010MW	41	8CB050200AO60001	47	KRA1806007000	44
1UA015095C300	50	4N630103008JGCD0	37	66MC	69	8CB050300AO30001	47	KRA1806009000	44
1UA025165B200	50	4N630103008JGC10	37	66MD	69	8CB-35035AA60001	47	KRA-250252200	44
1UA-10130B200	50								
1XA015095A200	64	4N630105008JGC10	37	66MD003000071	42	8CB-35035AO60001	47	KRA2807008000	44
1XA015095C300	64	4R05EJ050RMDCSV047	60	66ME	69	8GB004040AA60001	43	KUA0000502000	44
1XA025165B200	64	4R05EJ055RMCCSVF41	60	66MF	69	8GB004040AA80001	43	KUA0000701200	44
1XA-10130B200	64	4R05EJ055RMCCSVF44	60	66MF006000001	42	8GB004040AO60001	43	KUA0000705200	44
2DNAP6F0	54	4R05EJ065RMDCSVF44	60	66MG	69	8GB030090AO60001	43	KUA0101501000	44
2DNAP6FA	54	4R05EJ070RMDCSVM47	60	66MI	69	8GB030110AO60001	43	KUA0101505000	44
2DNAP6FB	54	4R05EJ075RMDCSVF44	60	66MJ	69	8GB050200AO60001	43	KUA0104507000	44
2DNAP6FB 2DNAP6FC	54	4R05EJ075RMDCSVM47	60	66MK	69	8GB050300AO30001	43	KUA0104509000	44
2DNAP6FD	54	4R05EJ085RMDCSVF44	60	66ML	69	8GB-10040AA60001	43	KUA0200901000	44
		4R05EJ090RMDCSVF44	60	66MM	69	8GB-10040AO60001	43	KUA0200905000	44
2DNAP6FE	54	4R05EJ090RMDL6VM37	60	66MN	69	8GB-35035AA60001	43	KUA0503000100	44
2DNAP6FF	54	4R05EJ120RMDCSVF44	60	66MP	69	8GB-35035AA60001 8GB-35035AO60001	43	KUA0605007000	44
2DNAP6FG	54	4R05EJ120RMDCSVF44 4R05NJ150RMEL6HM37		66MP0060040402FW		8HQ004040AO6A001	43		44
2DNAP6FH	54		60		45.46			KUA0605009000	
2DNAP6FI	54	5MA3SPF070019340	65	66MP0060040402FX	45.46	8HQ030090AO6A001	45	KUA0802000100	44
2DNAP6FJ	54	5MA3SPF070F18500	66	66MP0060300901FW	45.46	8HQ030110AO6A001	45	KUA-100152200	44
2DNAP6FK	54	5MA3SPF070H19340	65	66MP0060300901FX	45.46	8HQ050000AO6A001	45	KUA1806007000	44
2DNAP6FL	54	5MA3SPF077019340	65	66MP0060301101FW	45.46	8HQ050200AO6A001	45	KUA1806009000	44
2PE2N6	53	5MA3SPF077F18500	66	66MP0060301101FX	45.46	8IC085110AO60001	57	KUA-250252200	44
2PMR100	53	5MA3SPF077H19340	65	66MP0060502001FW	45.46	8JQ004040AO6A001	46	KUA2807009000	44
35ER101TF230V	42	5MA3SPF084019340	65	66MP0060502001FX	45.46	8JQ030090AO6A001	46	KXC0000502000	59
35ER102TF024V	42	5MA3SPF084F18500	66	66MP0060503001FW	45.46	8JQ030110AO6A001	46	KXC0000701200	59
	42	5MA3SPF084H19340	65	66MP0060503001FX	45.46	8JQ050000AO6A001	46	KXC0000705200	59
35ER102TF048V		5MA3SPF091019340	65	66MQ	69	8JQ050200AO6A001	46	KXC0101501000	59
35ER104TF400V	42	5MA3SPF091F18500	66	66MR	69	8L0080105AA61001	58	KXC0101505000	59
35ER105TF110V	42	5MA3SPF091H19340		66MS	69	8L0080105AO61001	58		59
4903EJ00905CCSV037	38		65					KXC0104507000	
4903EJ00905CCSVM37	39	5MA3SPF096019340	65	66MU	69	8L0090115AO61001	58	KXC0104509000	59
4903EJ01006CL6H0	40	5MA3SPF096F18500	66	66MV****	71	8L0110135AO61001	58	KXC0200901000	59
4903EJ01006CL6MF	40	5MA3SPF096H19340	65	66MW****	71	8L0130155AO61001	58	KXC0200905000	59
4903EJ01006CUSV0	40	5MA3SPF106019340	65	66MZ	43,44,47,53,57,71	8L0150175AO61001	58	KXC0503000100	59
4903EJ01808CL6VM37	39	5MA3SPF106F18500	66	66MZ	69	8L0175200AO41001	58	KXC0605007000	59
4903EJ04010CCSVF44	39	5MA3SPF106H19340	65	66MZ0060000502FW	44	8L0220245AO41001	58	KXC0605009000	59
4903EJ04512CL6V037	39	5MA3SPF109019340	65	66MZ0060000502FX	44	8L0270295AO41001	58	KXC0802000100	59
4903EJ04512CL6VM37	39	5MA3SPF109F18500	66	66MZ006000703FW	44	8L0300325AO41001	58	KXC-100152200	59
	39	5MA3SPF109H19340	65	66MZ0060000703FX	44	8X0060090CA61001	62	KXC1806007000	59
4903EJ05010DCSVF47		5MA3SPF121019340	65	66MZ0060040402FW	43.47	8X0060090Cl61001	62	KXC1806009000	59
4903EJ05010DL6VM39	39	5MA3SPF121615540	66	66MZ0060040402FW	53	8X0070100Cl61001	62	KXC-250252200	59
4903EJ05510DCSVF44	39								
4903EJ06010CL6HM37	39	5MA3SPF121H19340	65	66MZ0060040402FX	43.47	8X0080110Cl61001	62	KXC2807009000	59
4903EJ06010CL6VM37	39	5MA3SPF129019340	65	66MZ0060040402FX	53	8X0090120Cl61001	62	SRA00005000450	48
4903EJ06010DCSV037	39	5MA3SPF129F18500	66	66MZ0060101503FW	44	8X0110140Cl61001	62	SRA00010000230	48
4903EJ06010DCSVF34	39	5MA3SPF129H19340	65	66MZ0060101503FX	44	8X0130160Cl61001	62	SRA00015000170	48
4903EJ06010DCSVM37	39	5MA3SPF139019340	65	66MZ006014503FW	44	8X0150180Cl61001	62	SRA01006000450	48
4903EJ06015DCSVF34	39	5MA3SPF139F18500	66	66MZ006014503FX	44	8X0170200Cl61001	62	SRA03009000380	48
4903EJ06510CL6V037	39	5MA3SPF139H19340	65	66MZ0060200903FW	44	9BBAE1000000011C	74	SRA04014000230	48
4903EJ06510DCSVF47	39	5MA3SPF152019340	65	66MZ0060200903FX	44	9BBAE100000015A	74	SUA00005000450	48
4903EJ06510DL6VF39	39	5MA3SPF152F18500	66	66MZ0060300854FW	57	9BBAE100000017A	60	SUA00010000230	48
4903EJ07010CL6VF37	39	5MA3SPF152H19340	65	66MZ0060300854FX	57	9BBAE100000040A	74	SUA00015000170	48
	39	5MA3SPF165019340	65	66MZ0060300901FW	43.47	9BBAE1000000041A	74	SUA01006000450	48
4903EJ07010DCSVF34 4903EJ07020DL6VM37	39	5MA3SPF165F18500	66	66MZ0060300901FW	53	9BBBT100000006A	74	SUA03009000380	48
4903EJ07510DCSVF34	39	5MA3SPF165H19340	65	66MZ0060300901FX	43.47	9BBBT1M00ELH025D	74	SUA04014000230	48
4903EJ07510DCSVF44	39	5MA3SPF169019340	65	66MZ0060300901FX	53	9BBJ01000004015A	74	TNR60030C20001F	53
4903EJ08016DL6HM37	39	5MA3SPF169F18500	66	66MZ0060301101FW	43.47	9BBJ01000004017A	74	TNR60030C20001F	54
	39	5MA3SPF169H19340	65	66MZ0060301101FX	43.47		73	TPR40030C20001F	53
1003E10891901 CV/0427								TSR50030I2000BK6	54
				66M7006031101EW	53	9BBJ0100004008A 9BBJ01000ELH058A	74		
4903EJ08818DL6VM37 4903EJ09510CCSVF44	39	5MA3SPF182019340	65 66	66MZ006031101FW 66MZ006031101FX	53	9BBJ01000ELH058A	74 73		
4903EJ09510CCSVF44 4903EK07010CL6VM37	39 39	5MA3SPF182019340 5MA3SPF182F18500	66	66MZ006031101FX	53	9BBJ01000ELH058A 9BBJ01000ELH095A	73	VRA00010000300	49
4903EJ09510CCSVF44 903EK07010CL6VM37 910NP15514EL6VM37	39 39 38	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182H19340	66 65	66MZ006031101FX 66MZ0060502001FW	53 43.47	9BBJ01000ELH058A 9BBJ01000ELH095A 9BBJ01000004010A	73 72	VRA00010000300 VRA00010000450	49 49
4903EJ09510CCSVF44 1903EK07010CL6VM37 1910NP15514EL6VM37 4911NP01006CL6H0	39 39 38 40	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182H19340 5MA3SPF188019340	66 65 65	66MZ006031101FX 66MZ0060502001FW 66MZ0060502001FW	53 43.47 53	9BBJ01000ELH058A 9BBJ01000ELH095A 9BBJ0100004010A 9BBJ01000004015A	73 72 60	VRA00010000300 VRA00010000450 VRA00020000300	49 49 49
4903EJ09510CCSVF44 903EK07010CL6VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6MF	39 39 38 40 40	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182H19340 5MA3SPF188019340 5MA3SPF188F18500	66 65 65 66	66MZ006031101FX 66MZ0060502001FW 66MZ0060502001FW 66MZ0060502001FX	53 43.47 53 43.47	9BBJ01000ELH058A 9BBJ01000ELH095A 9BBJ0100004010A 9BBJ01000004015A 9BBJ01000004017A	73 72 60 60	VRA00010000300           VRA00010000450           VRA00020000300           VRA0003000300	49 49 49 49
1903EJ09510CCSVF44 903EK07010CL6VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6MF 4911NP01006CUSV0	39 39 38 40 40 40	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182H19340 5MA3SPF188019340 5MA3SPF188F18500 5MA3SPF188H19340	66 65 65 66 65	66MZ006031101FX 66MZ0060502001FW 66MZ0060502001FW 66MZ0060502001FX 66MZ0060502001FX	53 43.47 53 43.47 53 53	9BBJ01000ELH058A 9BBJ01000ELH095A 9BBJ0100004010A 9BBJ01000004015A 9BBJ01000004017A 9BBJ01000004019A	73 72 60 60 60	VRA00010000300           VRA00010000450           VRA00020000300           VRA0003000300           VRA000450	49 49 49 49 49 49
903EI09510CCSVF44 903EK07010CL6VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6MF 4911NP01006CUSV0 911NP03308CL6HF39	39 39 38 40 40 40 38	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182F19340 5MA3SPF188019340 5MA3SPF188119340 5MA3SPF188119340 5MA3SPF216019340	66 65 65 66 65 65 65	66MZ006031101FX 66MZ0060502001FW 66MZ0060502001FW 66MZ0060502001FX 66MZ0060502001FX 66MZ0060503001FW	53 43.47 53 43.47 53 43.47	9BBJ01000ELH058A 9BBJ01000ELH095A 9BBJ01000004010A 9BBJ01000004015A 9BBJ01000004017A 9BBJ01000004019A 9BBJ01000004019A	73 72 60 60 60 74	VRA00010000300 VRA00010000450 VRA00020000300 VRA00030000300 VRA00040000450 VUA00010000300	49 49 49 49 49 49 49
903EJ09510CCSVF44 903EK07010CL6VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6MF 4911NP01006CUSV0 911NP03308CL6HF39	39 39 38 40 40 40	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182H19340 5MA3SPF188019340 5MA3SPF188H19340 5MA3SPF188H19340 5MA3SPF216019340 5MA3SPF216F18500	66 65 65 66 65 65 65 66	66MZ006031101FX 66MZ0060502001FW 66MZ0060502001FW 66MZ0060502001FX 66MZ0060502001FX 66MZ0060502001FW	53 43.47 53 43.47 53 43.47 53 53	98BJ01000ELH058A 98BJ01000ELH055A 98BJ01000004010A 98BJ01000004015A 98BJ01000004017A 98BJ01000004017A 98BJ01000004019A 98BJ01000004013A	73 72 60 60 60 74 72	VRA00010000300 VRA00010000450 VRA0002000300 VRA00030000300 VRA00040000450 VUA00010000300 VUA00010000450	49 49 49 49 49 49 49 49
903EJ09510CCSVF44 903EK07010CL6VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6MF 4911NP01006CL5V0 911NP03308CL6HF39 911NP03806CCSV037	39 39 38 40 40 40 38	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182F19340 5MA3SPF188019340 5MA3SPF188119340 5MA3SPF188119340 5MA3SPF216019340	66 65 66 65 65 65 66 65	66MZ006031101FX 66MZ0060502001FW 66MZ0060502001FW 66MZ0060502001FX 66MZ0060502001FX 66MZ0060503001FW	53 43.47 53 43.47 53 43.47 53 43.47 53 43.47	9BBI01000ELH058A 9BBI01000EH055A 9BBI01000004010A 9BBI01000004017A 9BBI01000004017A 9BBI01000004019A 9BBI01000004019A 9BBI01000004019A	73 72 60 60 60 74 72 73	VRA00010000300 VRA0001000450 VRA00030000300 VRA00030000450 VLA00010000450 VLA00010000450 VLA00010000450	49 49 49 49 49 49 49 49 49
903EJ09510CCSVF44 903EK07010CL6VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6MF 4911NP01006CUSV0 911NP03806CC6VV037 911NP03806CCSV037	39 39 38 40 40 40 38 38 38 38	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182H19340 5MA3SPF188019340 5MA3SPF188H19340 5MA3SPF188H19340 5MA3SPF216019340 5MA3SPF216F18500	66 65 65 66 65 65 65 66	66MZ006031101FX 66MZ0060502001FW 66MZ0060502001FW 66MZ0060502001FX 66MZ0060502001FX 66MZ0060502001FW	53 43.47 53 43.47 53 43.47 53 53	98BJ01000ELH058A 98BJ01000ELH055A 98BJ01000004010A 98BJ01000004015A 98BJ01000004017A 98BJ01000004017A 98BJ01000004019A 98BJ01000004013A	73 72 60 60 60 74 72	VRA00010000300 VRA00010000450 VRA0002000300 VRA00030000300 VRA00040000450 VUA00010000300 VUA00010000450	49 49 49 49 49 49 49 49
9932E/09510CCSVF44 993Ek07010CL6VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6HF 4911NP01006CL6V50 911NP03308CL6H739 911NP03806CCSVM37 911NP03806CC5VM37	39 39 38 40 40 38 38 38 38 38 38	5MA3SPF182019340 5MA3SPF182118500 5MA3SPF182119340 5MA3SPF188019340 5MA3SPF188119340 5MA3SPF188119340 5MA3SPF216019340 5MA3SPF216F18500 5MA3SPF216F19340	66 65 66 65 65 65 66 65	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FW 66M20060503001FX	53 43.47 53 43.47 53 43.47 53 43.47 53 43.47	9BBI01000ELH058A 9BBI01000EH055A 9BBI01000004010A 9BBI01000004017A 9BBI01000004017A 9BBI01000004019A 9BBI01000004019A 9BBI01000004019A	73 72 60 60 60 74 72 73	VRA00010000300 VRA0001000450 VRA00030000300 VRA00030000450 VLA00010000450 VLA00010000450 VLA00010000450	49 49 49 49 49 49 49 49 49
I933E/09510CCSVF44 903Ek07010CL6VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6H4 911NP01006CL6H53 911NP03806CCSV037 911NP03806CCSV037 911NP03806CCSV037 911NP04010DCSV037	39 39 38 40 40 40 38 38 38 38 38 38 38 38	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182H19340 5MA3SPF188119340 5MA3SPF188119340 5MA3SPF188119340 5MA3SPF216F18500 5MA3SPF216F18500 5MA3SPF216F19340 5MA3SPF27019340	66 65 66 65 65 65 66 65 65 65 65	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FW 66M20060503001FX	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53	9680/0000ELH058A 9880/0000ELH058A 9880/000004010A 9880/000004015A 9880/000004015A 9880/000004019A 9880/000004019A 9880/00000ELH024A 9880/0000ELH024A	73 72 60 60 74 72 73 74	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
I933EI09510CCSVF44 903Ek07010CL6VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6HF 4911NP01006CLSV0 911NP03080CL6V5V37 911NP03806CCSV037 911NP03806CL5V037 911NP04010DCSV037	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182H19340 5MA3SPF188119340 5MA3SPF188H19340 5MA3SPF188H19340 5MA3SPF216019340 5MA3SPF216119340 5MA3SPF227119340 5MA3SPF227119340	66 65 66 65 65 65 65 65 66 66 65	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FX 66M20060503001FX 66M20060503003FX	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           44           44	9BBI01000ELH058A 9BBI01000EH055A 9BBI01000004010A 9BBI01000004017A 9BBI01000004017A 9BBI01000004017A 9BBI0100004013A 9BBI0100004013A 9BBI010000EH025A 9BBI01000EH025A 9BBI010005PH002A	73 72 60 60 74 72 73 74 73 74 73 74 73 74	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4903EI09510CCSVF44 903EK07010CL6VM37 910NP15514EL6VM37 4911NP0106CL6H0 4911NP01006CL6HF 4911NP01006CL6HF 9911NP0308CC4V73 911NP03806CCSVM37 911NP03806CCSVM37 911NP04010DCSV037 911NP04010DCSVM37	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	5MA35PF182019340 5MA35PF182118500 5MA35PF182119340 5MA35PF188019340 5MA35PF188019340 5MA35PF188119340 5MA35PF216019340 5MA35PF216119340 5MA35PF227119340 5MA35PF227119340 5MA35PF227119340	66 65 65 65 65 65 65 65 65 65 65 65 65	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FX 66M20060503001FX 66M20060503001FX 66M20060503003FW 66M20060503003FW	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           43.47           43.47           43.47           44           44           44	9BBI01000ELH058A 9BBI01000EH055A 9BBI01000004010A 9BBI01000004017A 9BBI01000004017A 9BBI01000004017A 9BBI0100004019A 9BBI0100004019A 9BBI010000EH025A 9BBI01000EH002A 9BBI010005FH002A 9BBI010005FH002A	73 72 60 60 74 72 73 73 74 73 74 74 74	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4903EI09510CCSVF44 903E0N7010CL6VM37 4911NP01006CL6H0 4911NP01006CL6H0 4911NP01006CL6H7 911NP03006CL5V0 911NP03006CCSV037 911NP03006CCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP040100CSV647 911NP05010CL6H37	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182F19340 5MA3SPF188019340 5MA3SPF188119340 5MA3SPF188119340 5MA3SPF216019340 5MA3SPF216119340 5MA3SPF227119340 5MA3SPF227119340 5MA3SPF227119340 5MA3SPF227119340	66 65 66 65 65 65 65 65 65 65 65 65 65 6	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FX 66M20060503001FX 66M20060503003FX	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           44           44           44           44           44           44           44	9680/1000ELH058A 9880/1000ELH058A 9880/1000004010A 9880/1000004015A 9880/1000004015A 9880/1000004019A 9880/1000004019A 9880/10000ELH024A 9880/1000ELH024A 9880/1000EH002A 9880/10005PH006A 9880/10005PH006A	73 72 60 60 74 72 73 74 73 74 74 73 74 73	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4903EI09510CCSVF44 903E0N7010CL6VM37 4911NP01006CL6H0 4911NP01006CL6H0 4911NP01006CL6H7 911NP03006CL5V0 911NP03006CCSV037 911NP03006CCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP040100CSV647 911NP05010CL6H37	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	5MA3SPF182019340 5MA3SPF182119340 5MA3SPF182119340 5MA3SPF188019340 5MA3SPF188119340 5MA3SPF188119340 5MA3SPF216019340 5MA3SPF216119340 5MA3SPF227019340 5MA3SPF227119340 5MA3SPF227119340 5MA3SPF2400119340	66 65 66 65 65 65 65 66 65 65 65 65 65 6	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FW 66M20060503001FX 66M2006050300FX 66M2006050300FX 66M200605003FX 66M2006005003FX 66M2006005003FW	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           44           44           44           44           44           44           44	9BBI01000ELH058A 9BBI01000EH055A 9BBI01000004010A 9BBI01000004015A 9BBI01000004015A 9BBI01000004019A 9BBI01000004019A 9BBI010000EH025A 9BBI010000EH025A 9BBI010005PH006A 9BBI010005PH006A 9BBI010005PH006A 9BBI010005PH016A	73 72 60 60 74 72 73 74 73 74 73 74 74 73 74 73 74 73	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4903EI09510CCSVF44 903EK07010CL6VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6HF 4911NP01006CL6HF3 911NP03806CCSV037 911NP03806CL6V037 911NP03806CL5V037 911NP0410DCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP04010DCSV037	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182H19340 5MA3SPF188119340 5MA3SPF188H19340 5MA3SPF188H19340 5MA3SPF216019340 5MA3SPF216F18500 5MA3SPF227H19340 5MA3SPF227H19340 5MA3SPF227H19340 5MA3SPF227H19340 5MA3SPF240H19340 5MA3SPF240H19340	66 65 65 65 65 65 65 65 65 65 65 65 65 6	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060503001FW 66M20060503001FW 66M20060503001FX 66M20060503001FX 66M20060503001FX 66M20060503003FW 66M2006050303FW 66M2006050303FW 66M200605003FX	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           44	9BBI01000ELH058A 9BBI01000EH055A 9BBI01000004010A 9BBI01000004017A 9BBI01000004017A 9BBI01000004019A 9BBI01000004019A 9BBI01000004019A 9BBI0100006H02A 9BBI0100005H02A 9BBI010005FH02A 9BBI010005FH012A 9BBI010005FH012A	73 72 60 60 74 72 73 73 74 73 74 74 74 73 74 74 74 74	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4903EI09510CCSVF44 903EK07010CL5VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6HF 911NP0308CL6HF39 9911NP0308CCSV037 911NP03806CCSV037 911NP03806CCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP05010CL6H637 9011NP05010CL6HF37	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	5MA3SPF182019340 5MA3SPF182119340 5MA3SPF182119340 5MA3SPF188019340 5MA3SPF188119340 5MA3SPF188119340 5MA3SPF216019340 5MA3SPF216119340 5MA3SPF227019340 5MA3SPF227119340 5MA3SPF227119340 5MA3SPF2400119340	66 65 66 65 65 65 65 65 65 65 65 65 65 6	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FW 66M20060503001FX 66M2006050300FX 66M2006050300FX 66M200605003FX 66M2006005003FX 66M2006005003FW	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           44           44           44           44           44           44           44           44           44           44           43	9BBI01000ELH058A 9BBI01000EH055A 9BBI01000004010A 9BBI01000004015A 9BBI01000004015A 9BBI01000004019A 9BBI01000004019A 9BBI010000EH025A 9BBI010000EH025A 9BBI010005PH006A 9BBI010005PH006A 9BBI010005PH006A 9BBI010005PH016A	73 72 60 60 74 72 73 74 73 74 74 74 73 74 74 74 74 74	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4903EJ09510CCSVF44 4903EK07010CL6VM37 4911NP01006CL6H0 4911NP01006CL6H0 4911NP01006CL6H7 4911NP01006CL6WF 4911NP03006CCSV037 911NP03806CCSV037 911NP03806CCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP0510DL6H733 1911NP0510DL6H733 1911NP0510DL6H733 1911NP07010DCSV037	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182H19340 5MA3SPF188119340 5MA3SPF188H19340 5MA3SPF188H19340 5MA3SPF216019340 5MA3SPF216F18500 5MA3SPF227H19340 5MA3SPF227H19340 5MA3SPF227H19340 5MA3SPF227H19340 5MA3SPF240H19340 5MA3SPF240H19340	66 65 65 65 65 65 65 65 65 65 65 65 65 6	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060503001FW 66M20060503001FW 66M20060503001FX 66M20060503001FX 66M20060503001FX 66M20060503003FW 66M2006050303FW 66M2006050303FW 66M200605003FX	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           44	9BBI01000ELH058A 9BBI01000EH055A 9BBI01000004010A 9BBI01000004017A 9BBI01000004017A 9BBI01000004019A 9BBI01000004019A 9BBI01000004019A 9BBI0100006H02A 9BBI0100005H02A 9BBI010005FH02A 9BBI010005FH012A 9BBI010005FH012A	73 72 60 60 74 72 73 73 74 73 74 74 74 73 74 74 74 74	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4903EI09510CCSVF44 903Ek07010CL6VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6H7 4911NP01006CL6H7 911NP03066CCSV037 911NP03066CCSV037 911NP03066CCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP05100L6H737 911NP055100L6H737 911NP055100L6H737 911NP05100L6H737 911NP05100L6H737 911NP05100L6H737	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	5MA3SPF182019340 5MA3SPF182F13500 5MA3SPF182F13940 5MA3SPF188019340 5MA3SPF188119340 5MA3SPF188119340 5MA3SPF216019340 5MA3SPF216119340 5MA3SPF227019340 5MA3SPF227119340 5MA3SPF227119340 5MA3SPF227119340 5MA3SPF240119340 5MA3SPF240119340 666F1 666F1	66 65 66 65 65 65 65 65 65 65 65 65 65 6	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FX 66M20060503001FX 66M20060503001FX 66M20060503003FW 66M20060503003FW 66M20060605003FW 66M20060605003FW 66M20060605003FW	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           44           44           44           44           44           44           44           44           44           44           43	9680/1000ELH058A 9880/1000ELH058A 9880/100004015A 9880/100004015A 9880/100004015A 9880/100004019A 9880/1000004019A 9880/10000ELH024A 9880/1000ELH024A 9880/1000EH002A 9880/10005PH006A 9880/10005PH016A 9880/10005PH016A 9880/10005PH016A	73 72 60 60 74 72 73 74 73 74 74 74 73 74 74 74 74 74	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4903EI09510CCSVF44 903EK07010CL5VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6H7 911NP03006CCSV037 911NP03806CCSV037 911NP03806CCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP05010CL6H33 911NP05010DL6H33 911NP05010DL6H33 911NP05010DL6H33 911NP05010DL6H33	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	5MA3SPF182019340 5MA3SPF182F18500 5MA3SPF182H19340 5MA3SPF188119340 5MA3SPF188119340 5MA3SPF188119340 5MA3SPF216019340 5MA3SPF216119340 5MA3SPF220F18500 5MA3SPF227H19340 5MA3SPF227H19340 5MA3SPF240F18500 5MA3SPF240F18500 5MA3SPF240F18500 5MA3SPF240F18500 5MA3SPF240F19340 668F1 668F1 668F3 668F3	66           65           66           65           66           65           66           65           66           65           66           65           66           65           74           74           71	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FX 66M20060503003FX 66M20060503003FX 66M20060503003FX 66M20060503003FX 66M2006050303FX 66M2006050303FX 66M2006050303FX 66M20060503FX 66M2006-100153FX 66M2006-100153FX 66M2006-100153FX 66M2006-100153FX 66M2006-100153FX	53           43.47           53           43.47           53           43.47           53           43.47           53           44.4           44           44           44           44           44           43           43	9BBI01000ELH058A 9BBI01000EH055A 9BBI01000004010A 9BBI01000004015A 9BBI01000004017A 9BBI01000004017A 9BBI01000004019A 9BBI010000EH022A 9BBI010000EH022A 9BBI010005PH02A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A	73 72 60 60 74 72 73 74 74 74 74 74 74 74 74 74 74 74 74 74	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4903EJ09510CCSVF44 4903EK07010CL6VM37 4911NP01006CL6H0 4911NP01006CL6H0 4911NP01006CL6M7 4911NP01006CL6M7 4911NP03006CCSV037 911NP03806CCSV037 911NP03806CL6V037 911NP04010DCSV037 911NP04010DCSV037 911NP0510DL6H739 911NP0510DL6H739 911NP07010DCSV037 911NP07010DCSV037 911NP07010DCSV037 911NP07010DCSV037	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	SMA3SPF182019340           SMA3SPF182119300           SMA3SPF182119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF126119340           SMA3SPF216119340           SMA3SPF227019340           SMA3SPF22719340           SMA3SPF240019340           SMA3SPF240019340           SMA3SPF240119340           G6BF1           66BF3	66 65 65 65 65 65 65 65 65 65 65 66 65 65	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FX 66M20060503001FX 66M20060503001FX 66M20060503003FX 66M20060503003FX 66M20060503003FX 66M20060503003FX 66M2006100153FW 66M2006-100125FW 66M2006-100125FW 66M2006-100402FX	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           44.44           44           44           44           44           44           43           43           43           44	9680/1000ELH058A 9880/1000EH055A 9880/100004010A 9680/100004015A 9680/100004015A 9680/100004019A 9680/100004019A 9680/10000EH02A 9680/10000EH02A 9680/10005PH00A 9680/10005PH00A 9680/10005PH01A 9680/10005PH01A 9680/10005PH01A 9680/10005PH01A 9680/10005PH01A	73 72 60 60 74 72 73 74 73 74 74 73 74 74 73 74 74 74 72	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4903EI09510CCSVF44 903EK07010CL5VM37 910NP15514EL5VM37 4911NP01006CL6H0 4911NP01006CL6H7 4911NP01006CL6H7 911NP03066CCSV037 911NP03066CCSV037 911NP03066CCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP05100L6H737 911NP05100L6H737 911NP05100L6H737 911NP07010DCSV037 911NP07010DCSV037	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	SMA3SPF182019340           SMA3SPF182F18500           SMA3SPF182F18500           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF26019340           SMA3SPF216119340           SMA3SPF27119340           SMA3SPF27119340           SMA3SPF240019340           SMA3SPF240119340           SMA3SPF240119340           SMA3SPF240119340           SMA3SPF240119340           G6BF1           G6BF3           G6BF3           G6BF3           G6BF01           G6BR02           G6BR03	66           65           66           65           66           65           66           65           66           65           66           65           66           65           66           65           66           74           74           71           71           71	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FX 66M20060503001FX 66M20060503003FX 66M20060503003FX 66M20060503003FW 66M2006050039FX 66M200605003FW 66M200605100402FX 66M2006-100402FX 66M2006-100402FX 66M2006-100402FX 66M2006-100402FX	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           44           44           44           44           44           43           43           44           44           44           43           43           44           43           44           43           44           44           44           44           44           44           44           44           44           44           44           44           44           44           44	9680/0000ELH058A 9880/000ELH058A 9880/000EH055A 9880/00004010A 9880/00004015A 9880/00004015A 9880/00004019A 9880/00004019A 9880/00002H02A 9880/00005PH002A 9880/0005PH002A 9880/0005PH002A 9880/0005PH002A 9880/0005PH012A 9880/0005PH012A 9880/0005PH012A 9880/0005PH012A 9880/0005PH012A 9880/0005PH012A 9880/0005PH012A 9880/0005PH012A 9880/0005PH012A 9880/0005PH012A 9880/0005PH012A	73 72 60 60 74 72 73 74 73 74 74 74 73 74 74 74 74 72 72 74 71	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4903EI09510CCSVF44 903Ek07010CL6VM37 910NP15514EL6VM37 4911NP01006CL6H0 4911NP01006CL6H7 911NP01006CL6H7 911NP03066CL6V037 911NP03066CL6V037 911NP03066CL6V037 911NP0306CL6H73 911NP04010DCSVM37 911NP0510CL6H737 911NP05100L6H737 911NP0510DCSVM37 911NP07010DCSVM37 911NP07010DCSVM37 911NP07010DCSVM37 911NP07010DCSVM37 911NP07010DC6XV37 911NP07010DC6XV37 911NP07010DC6XV37	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	SMA3SPF182019340           SMA3SPF182119300           SMA3SPF182119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF2166119340           SMA3SPF216119340           SMA3SPF227019340           SMA3SPF227119340           SMA3SPF240119340           SMA3SPF240119340           SMA3SPF240119340           G6BF1           66BF2           66BF3           66BF3           66BR01           66BR03           66CG12	66           65           66           65           66           65           66           65           66           65           66           65           66           65           66           65           66           65           74           74           71           71           71           71           71           71           71	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FX 66M20060503001FX 66M20060503003FX 66M20060503003FX 66M20060503003FX 66M20060503003FX 66M2006050303FX 66M2006-10042FW 66M2006-100402FW 66M2006-100402FW 66M2006-100402FW 66M2006-100402FW 66M2006-100402FW 66M2006-100402FW	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           44.44           44	9BBI01000ELH058A 9BBI010000H05A 9BBI0100004010A 9BBI01000004015A 9BBI01000004015A 9BBI01000004019A 9BBI01000004019A 9BBI010000ELH025A 9BBI010000ELH025A 9BBI010005PH002A 9BBI010005PH002A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI012A	73           72           60           60           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           71           71           71           71	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4933EJ09510CCSVF44 903ENP515LECEVM37 4911NP01006CL6M0 4911NP01006CL6M7 4911NP01006CL6M7 901NP03006CL5V07 911NP03006CCSV037 911NP03806CCSV037 911NP03806CCSV037 911NP04010DCSV037 911NP04010DCSV037 911NP05010CL6H37 911NP05010CL6H37 911NP07010DCSV037 911NP07010DCSV037 911NP07010L6H33 911NP07010L6H37 911NP07010L6H33 911NP07010L6H33 911NP07010L6H33 911NP07010L6H33 911NP07010L6H33 911NP07010L6H33 911NP07010L6H33 911NP07010L6H33	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	5MA3SPF182019340 5MA3SPF182F13500 5MA3SPF182F13940 5MA3SPF188019340 5MA3SPF188119340 5MA3SPF188119340 5MA3SPF216019340 5MA3SPF216119340 5MA3SPF216119340 5MA3SPF227019340 5MA3SPF227119340 5MA3SPF227119340 5MA3SPF227019340 5MA3SPF240019340 5MA3SPF240019340 66BF1 66BF1 66BF1 66BF2 66BF3 66BR02 66BR03 666R03 666C612	66           65           66           65           66           65           66           65           66           65           66           65           66           65           74           74           71           71           71           71           71           71           71           71           71           71           71	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060503001FW 66M20060503001FW 66M20060503001FX 66M20060503001FX 66M20060503001FX 66M20060503003FW 66M2006050303FW 66M2006050303FX 66M200605003FX 66M2006100153FX 66M2006100153FX 66M2006100153FX 66M2006100153FX 66M2006100153FX 66M2006100153FX 66M2006100153FX 66M2006100153FX 66M2006100153FX 66M2006100153FX 66M20061804003FX	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           44	9680/1000ELH058A 9880/1000ELH058A 9880/100004015A 9880/100004015A 9880/100004015A 9880/100004019A 9880/1000004019A 9880/10000ELH024A 9880/1000ELH024A 9880/1000EH002A 9880/10005PH006A 9880/10005PH006A 9880/10005PH016A 9880/10005PH016A 9880/10005PH016A 9880/10005PH016A 9880/10005PH016A 9880/10005PH016A 9880/10005PH016A 9880/10005PH016A 9880/10005PH016A 9880/10005PH016A 9880/10005PH016A 9880/10005PH016A 9880/10005PH016A	73         72         60         60         74         73         74         73         74         73         74         73         74         73         74         73         74         73         74         73         74         71         71         41	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49
4903EI09510CCSVF44 903EK07010CL5VM37 4911NP01006CL6M0 4911NP01006CL6M0 4911NP01006CL6M7 911NP03006CL5V0 911NP03806CCSV037 911NP03806CCSV037 911NP03806CL6V037 911NP04010DCSV037 911NP04010DCSV037 911NP05100L6H739 911NP05100L6H739 911NP07010DCSV037 911NP07010DCSV037 911NP07010DCSV037 911NP07010DCSV037	39 39 38 40 40 38 38 38 38 38 38 38 38 38 38 38 38 38	SMA3SPF182019340           SMA3SPF182119300           SMA3SPF182119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF188119340           SMA3SPF2166119340           SMA3SPF216119340           SMA3SPF227019340           SMA3SPF227119340           SMA3SPF240119340           SMA3SPF240119340           SMA3SPF240119340           G6BF1           66BF2           66BF3           66BF3           66BR01           66BR03           66CG12	66           65           66           65           66           65           66           65           66           65           66           65           66           65           66           65           66           65           74           74           71           71           71           71           71           71           71	66M2006031101FX 66M20060502001FW 66M20060502001FW 66M20060502001FX 66M20060502001FX 66M20060503001FW 66M20060503001FX 66M20060503001FX 66M20060503003FX 66M20060503003FX 66M20060503003FX 66M20060503003FX 66M2006050303FX 66M2006-10042FW 66M2006-100402FW 66M2006-100402FW 66M2006-100402FW 66M2006-100402FW 66M2006-100402FW 66M2006-100402FW	53           43.47           53           43.47           53           43.47           53           43.47           53           43.47           53           44.44           44	9BBI01000ELH058A 9BBI010000H05A 9BBI0100004010A 9BBI01000004015A 9BBI01000004015A 9BBI01000004019A 9BBI01000004019A 9BBI010000ELH025A 9BBI010000ELH025A 9BBI010005PH002A 9BBI010005PH002A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI010005PH012A 9BBI012A	73           72           60           60           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           73           74           71           71           71           71	VRA00010000300           VRA00010000450           VRA00020000300           VRA00030000450           VRA00010000450           VUA00010000450           VUA00010000450           VUA0002000300           VUA0002000300           VUA0002000300           VUA0002000300	49 49 49 49 49 49 49 49 49 49

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr



Unless exceptionally specified by this logo 📥 , products and components in this catalogue are made by Ultimheat alliance members.

	Page
AC and DC	14
Accessories	69
Adjustable differential contacts	19
Air displacement thermostat	23
Air ducts thermostats, installation	28
Anticipative control action	5
Antifreeze protection disc thermostat	40
Automatic reset	16
Bellows	6
Bezels	71
Bilame thermostat, definition	19
Biling style failsafe systems	17
Bimetal	4
Bimetal rod thermostat	21
Bimetal strip	4
Blind electronic thermostat	53
Boiling Boiling thermestat	8
Boiling thermostat Bonnemain Jean-Simon	23
	_
Brackets	72, 73, 74
Bulb	6
Bulb and capillary thermostat	21
Bulb and capillary thermosts, installation	28
Calorstat	23
Capillary	6
Capillary thermostat, definition	23
Cartridge	5
Cartridge thermostat, definition	20
CEI 61508	26
Change over contacts	19
Clips, arrow style for shaft	69
Combistat	25
Contact (material)	10
Contact gap	10
Contact thermostat, definition	20
Contacts contamination	15
Contacts oxidation	15
Contacts protection	15
Converter for bracket rotation	72
Counter-plate	71
Cover for fixed setting	72
Curie point	8
Cycling speed	15
Description of temperature controls	30
Dials	71
Dials, traditional enameled	71
Diastat	6
Digital display thermostat for DIN rail	54
Disc	4
Disc thermostat	38,
	39,40
Disc thermostat accessories	75.76
Double metal expansion	5
Double pole high rating bulb and capillary thermostat	46
DPNC manual reset high limit, fail safe	62
Electrical contacts	9
	10
Electrical life	13
Electrical life Electrical life of a thermostat	
Electrical life of a thermostat	16
Electrical life of a thermostat Electrical reset	16 37 to 50
Electrical life of a thermostat Electrical reset Electromechanical thermostats	37 to 50
Electrical life of a thermostat Electrical reset Electromechanical thermostats Electronic thermostat for incorporation	37 to 50 53
Electrical life of a thermostat Electrical reset Electromechanical thermostats Electronic thermostat for incorporation Electronic thermostats	37 to 50 53 53.54
Electrical life of a thermostat Electrical reset Electromechanical thermostats Electronic thermostat for incorporation Electronic thermostats Energy regulators	37 to 50 53 53.54 42
Electrical life of a thermostat Electrical reset Electromechanical thermostats Electronic thermostat for incorporation Electronic thermostats	37 to 50 53 53.54

Fail safe	16
Fittings	75
Flameproof contacts	19
Flameproof enclosure contacts	19
Flameproof enclosures	19
Flanges	73
Flat disc thermostat	37
Form memory	8
Fuse alloys	8
Gas expansion thermostat	22
Gaskets	72
Grande Cuisine accessories	71
Grommets for pockets	73
Heat accumulation	28
High frequency	15
Hinges for glass doors	71
Housing for disc thermostats	38
IEC 60335-1	26
IEC 60446	26
Inductive loads correction factor	12
Installation	27
Invar	5
lpsotherm	25
Klixon	25
Knobs	69
Knobs, massive brass	71
Liquid expansion	5
Liquid expansion thermostat	21
Liquid expansion type failsafe system	18
Liquid metalloids	6
Liquid metals	5 71
Logos, embossed with folding legs Manual reset	16
Manual reset rod thermostat	64
Mixed contacts	19
Motors loads impulse voltage	13
	71
Mounting board Neutral zone contacts	19
Number of cycles	10
One shot	10
Overheat	28
Overmold disc thermostats	38
Overvoltage peak	12
Pipe thermostat	22
Pocket grommets	73
Pockets	73
Printed values made on a thermostat	11
Reset by temperature drop	16
Resistive or inductive circuit	11
Response time	27
Rod	5
Rod coolers	73
Rod thermostat DPST and SPDT	50
Rod thermostat with dead zone	49
Rod thermostats, installation	28
Room thermostat, definition	22
Self regulating cables inrush current surge	13
Shaft gaskets	72
Shifting angle	11
Simultaneous contacts	19
Single pole bulb and capillary thermostat, appli- ance type	43
Single pole bulb and capillary thermostat, com- mercial type	44
Single pole high rating bulb and capillary thermostat	45
Single pole manual reset disc thermostat	60
Slow break	9
Snap action	9

Snap action 1/2" disc thermostat 10A250V	38
Snap action 1/2" disc thermostat 16A250V	39
SPDT Bimetal rod thermostat	48
SPDT manual reset high limit, adjustable, com- mercial type	59
Special and prestigious achievements	71
SPNC manual reset high limit, fail safe	58
Staggered contacts	19
Standards	26
State change	8
Stop for knob	70.72
Summary Surface mounting thermostat	1 41
Temperature control	16
Thermal conductivity	27
Thermal cut out, axial wires	65
Thermal cut out, installation	29
Thermal drift	6
Thermal fuse	66
Thermal fuse (definition)	23
Thermostat boots	74
Thermostats application	24
Three pole combination control thermostat	57
Three pole control thermostat	47
Three pole manual reset disc thermostat	61
Three pole manual reset high limit, fail safe	63
Through wall waterproof gaskets	72
Time needed to heat	27
Type 1B, 1C, 1R, 1U	50
Type 1D,1X	64
Type 2DNAP6	54
Type 2PE2N6	53
Type 35ER	42
Type 4903	39
Type 4911	38
Type 4C	61 37
Type 4N630	60
Type 4R05 Type 5MA3	65
Type 5MA3-F	66
Type 82	63
Туре 8С	47
Type 8G	43
Туре 8Н	45
Туре 81	57
Туре 8Ј	46
Type 8L	58
Туре 8Х	62
Туре ІВ	41
Туре КК	44
Туре КU	44
Туре КХ	59
Type SR	48
Type SU	48
Type VR	49
Туре VU	49
Vigitherme	25
Wafer room thermostat	22
Wall thermostats, installation	28
waii thermostats, installation	
Winding thermostats, installation	29
	29 38

Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr
# **Control Thermostats**





## Waterproof flat disc thermostat, 4A 250V Type 4N630

#### DIMENSIONS





#### **TECHNICAL FEATURES**

**Application:** Waterproof thermostat, can be incorporated inside thin heating devices, heating blankets, heating pads, antifreeze cables, electrical floor heating

Electrical rating: 8A,125VAC res

4A, 250VAC res

Temperature calibration range: 0 to 120°C (32 to 248°F)

Contact: open or close on temperature rise

Differential: 8-15°C (46.4-59°F)

**Tolerance:** ±5°C on open and close

**Contact resistance:** < 70 m $\Omega$  (wires and optional TCO not included)

Insulation resistance:  $\geq 100M\Omega$  @500VDC

Thermal resistance: -20°C +130°C (except optional thermal fuse and wires)

Electrical life: ≥10.000 cycles under rated load

Wires: PVC insulated, 0.5 mm<sup>2</sup> (0.75 mm<sup>2</sup> on request), length 100, 200, 500, 1000 mm

**Option:** built-in thermal fuse, 2A, 5A or 8A.

Thermal fuse calibration must be at least 30°C higher than thermostat opening temperature (MOQ apply)

4									
References	Open °C (°F)	Close °C (°F)	Wire lengths (mm)						
4N630101308JGCD0	13°C ±5°C (55.4 ±41°F)	6°C±5°C (42.8±41°F)	200						
4N630103008JGCD0	30°C±5°C (86 ±41°F)	22°C±5°C (71.6±41°F)	200						
4N630104008JGC10	40°C±5°C (104±41°F)	32°C±5°C (89.6±41°F)	1000						
4N630105008JGC10	50°C±5°C (122±41°F)	42°C±5°C (107.6±41°F)	1000						

#### Main references



37

his catalogue are made by Ultimheat alliance members.

Unless exceptionally specified by this logo 📥 , products and componen

## Snap action 9 mm reduced thickness <sup>1</sup>/<sub>2</sub>" disc thermostat, 10A 250V, type 4911



Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

Products usually available from stock in one of the Ultimheat Alliance members \* Temperature in red= close on rise model

Ceramic body

#### These thermostats can be fitted inside various housings, overmolded and wired\*. Some examples:



38

## Snap action bimetal disc thermostat, 1/2" disc. 12 mm thickness, 16A 250V Type 4903





be modified without prior advice

gu

/ and (

guidance only

on these data sheets are for

ires used

featu

drawings, descriptions,

nent improvement of our products,

permar

lseof

g B

## Selection of defrost or antifreeze protection disc thermostats



## Surface mounting thermostats Type IB



#### **TECHNICAL FEATURES**

Applications: Precise and adjustable surface temperature control on heating plates, silicone heating pads, foil heaters

Housing dimensions: 58.5 x 17.5 x 17.5mm (shaft and bracket not included) Material: Metal /ceramic housing

Temperature sensing element: High conductivity copper alloy

Terminals: 2 x #6-32 screw terminals

Adjustment: Dia. 6.35mm round shaft, 32 mm length, 310° mechanical rotation, or screw adjustment (other lengths, rotation or fixed setting available on request) Mounting:

• Without bracket or with surface mounting bracket,

• 2 holes dia. 3.4 mm, 65.5 mm distance

Rating: 1500 watts 110/250VAC, resistive (Slow make and break action)

Contact: Open on temperature rise only

Differential: lower than 1° C

Max ambient temperature on housing: 300°C

Accessories: Knobs

Approval: Comply with UL 873 standard (limit or control)

#### Main references

References	Shaft length (L)	Bracket	High stop Temperature calibra- tion ° C (°F)	Approx. temperature span be- tween min. and max. position °C (°F)
IBJ2000608313001	Screw adjustment	No	150 (300)	160 (290)
IBJ2000608316002	Screw adjustment	No	315 (600)	330 (590)
IBK2000608313001	Screw adjustment	Yes	150 (300)	160 (290)
IBK2000608316002	Screw adjustment	Yes	315 (600)	330 (590)
IBJ2000632313001	32 mm	No	150 (300)	160 (290)
IBJ2000632315302	32 mm	No	275 (530)	330 (590)
IBJ2000632316002	32 mm	No	315 (600)	330 (590)
IBK2000632313001	32 mm	Yes	150 (300)	160 (290)
IBK2000632315302	32 mm	Yes	275 (530)	330 (590)
IBK2000632316002	32 mm	Yes	315 (600)	330 (590)





For 6.35 mm diameter shaft, black PPS, white crescent. Max temperature on knob 200°C/392°F

Reference 66MB060000010MW Other knobs that fit this type: see last section of this catalogue











**TECHNICAL FEATURES** 

#### Main features:

Energy regulators are used to adjust power on electrical heaters. Connected in line with electrical heaters, they provide adjustable cycling sequence, thus adjusting average electrical power

Housing dimensions: 50 x 42 x 39 mm (shaft not included)

Housing material: high temperature resistant PPS

Terminals: 6.3 x 0.8 quick connect

Adjustment: dia. 6 mm with 4.8 flat shaft, length 11.4 mm (UK style models with 4.75 mm dia. shaft available on request, MOQ apply)

Angulation:

- Mechanical: 360°, with two pole off position at 0°
- Electrical: Min position at 75° angular, Max position at 285° angular. (Other angulation with max at 208.5° available on request, MOQ apply)

Mounting: Center ¼ BSPP bush with centering studs. 2 M4, 28 mm distance screws mounting bracket available on request (MOQ apply)

Rating: 12A 230V resistive, SPDT+ on off pilot contact. Other contact configuration (SPST, SPDT without pilot, double circuit etc... are available on request, MOQ apply) Max ambient temperature: 125°C/257°F

#### Approval: CE

#### References

35ER102TF024V
35ER102TF048V
35ER105TF110V
35ER101TF230V
35ER104TF400V

his catalogue are made by Ultimheat alliance members.



Л⊇ 42

# Type 8G Single pole control thermostat (Appliances type)

#### DIMENSIONS



#### **TECHNICAL FEATURES**

Housing dimensions: 43 x 35 x 29 mm (without terminals) Bulb and capillary: stainless steel, 150 mm long pvc sleeve on capillary. Capillary minimum bending radius 5 mm. Temperature sensing element: liquid filled bulb and capillary.

Terminals: 6.35 x 0.8 quick connect terminals. M4 screws also available on request

on request. Adjustment: Dia. 6 mm shaft with 4.6 mm flat, length 11.5 mm. Other lengths, screw driver adjustment or fixed setting available on request. Mounting: Front bracket with 2 xM4 threads, 28 mm distance Rating: 16A(4) 250/VAC

Contacts: SPDT (snap action contact)



#### Main references

	Wall references								
Reference	Temperature range °C/°F	Capillary length (mm)	Bulb diameter (mm)	Bulb length (mm)-material	Differential °C/°F	Max temperature on bulb (°C)			
8GB-35035AO60001	-35+35°C (-30+95°F)	1500	6	120±5-CU	4±2°C (7±3.6 °F)	60°C (140°F)			
8GB-35035AA60001	-35+35°C (-30+95°F)	250	6	120±5-CU	4±2°C (7±3.6 °F)	60°C (140°F)			
8GB-10040AO60001	-10+40°C (15-105°F)	1500	6	107±5-CU	3±2°C (5.5±3.6 °F)	70°C (158°F)			
8GB-10040AA60001	-10+40°C (15-105°F)	250	6	107±5-CU	3±2°C (5.5±3.6 °F)	70°C (158°F)			
8GB004040AA80001	4-40°C (40-105°F)	250	8	85±5-CU	3±2°C (5.5±3.6 °F)	70°C (158°F)			
8GB004040AO60001	4-40°C (40-105°F)	1500	6	120±5-CU	3±2°C (5.5±3.6 °F)	70°C (158°F)			
8GB004040AA60001	4-40°C (40-105°F)	250	6	120±5-CU	3±2°C (5.5±3.6 °F)	70°C (158°F)			
8GB030090AO60001	30-90°C (85-195°F)	1500	6	98±5-SS	4±3°C (7±5.5 °F)	120°C (250°F)			
8GB030110AO60001	30-110°C (85-230°F)	1500	6	86±5-SS	5±3°C (9±5.5 °F)	140°C (284°F)			
8GB050200AO60001	50-200°C (120-390°F)	1500	6	65±5-SS	5°~13°C (9~24 °F)	230°C (446°F)			
8GB050300AO30001	50-300°C (120-570°F)	1500	3	145±5-SS	5~15°C (9 ~27°F)	330°C (626°F)			
Other temperature range	es available on request.								

#### °C Printed knobs -35+35°C -10+40°C 4-40°C 30-90°C 30-110°C 50-200°C 50-300°C

66MZ006-350352FW 66MZ006-100402FW 66MZ0060040402FW 66MZ0060300901FW 66MZ0060301101FW 66MZ0060502001FW 66MZ0060503001FW . . ..

			*F Printed knobs			
-30+95°F	15-105°F	40-105°F	85-195°F	85-230°F	120-390°F	120-570°F
						Carlos Carlos
66MZ006-350352FX	66MZ006-100402FX	66MZ0060040402FX	66MZ0060300901FX	66MZ0060301101FX	66MZ0060502001FX	66MZ0060503001FX

#### Soft grip knob and bezel dimensions

Dimensions	206mm 06mm 4.6mm	28mm (24.5mm (x4) 28mm 04.5mm (x4) 28mm 08mm 047mm	042mm 28mm (x4) 28mm 04.5mm (x4) 28mm 08mm 047mm	060mm 042mm 28mm 04.5mm (x4) 4.5mm
	and the second second			
References	66MZ	66EN1	66EN3	66EN2
Material	PC + Santoprene	Black ABS	Chrome plated ABS	Stainless steel
Many other kno	bs are available, see the full knob list at	the end of this catalogue.		

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr



ᆝᆯ

his catalogue are made by Ultimheat alliance members.

, products and componen

Unless exceptionally specified by this logo

# Types KR and KU, Single pole control thermostat, standard differential and reduced differential (Commercial type)

#### DIMENSIONS



Housing dimensions: 79 x 53 x 36 mm (without terminals) Bulb and capillary: copper for temperature ranges up to 50°C (122°F), stainless steel over, capillary length 1500 mm or 3000 mm. Capillary minimum bending radius 5mm. Temperature sensing element: liquid filled bulb and capillary. Terminals: 6.35 x 0.8 quick connect terminals (M4 screws also available on request), Adjustment: Dia. 6 mm shaft with 4.6 mm flat, (other lengths or fixed setting available on request). Mounting: Front bracket with 2 xM4 threads, 28 mm distance Rating: 15A (1/4 HP) 250VAC, 15A 400V res. KU type cannot be used on 400V Contacts: SPDT (snap action contact) Electrical life: >500,000 cycles at nominal rating Main references

4.6mm 10±1mm 51mg 53mm D Min Øß M4(X2) 2 29.5n 28mm 6.3x0.8mm(x3

References with References with Temperature range Capillary Bulb Bulb length KR: Standard KU: Reduced								
References with standard differential	References with reduced differential	Temperature range (°C/°F)	Capillary length (mm)	diameter (mm)	Bulb length (mm)	KR: Standard Differential (°C/°F)	KU: Reduced Differential (°C/°F)	Max temperature on bulb (°C/°F)
KRA-250252200	KUA-250252200	-25+25°C (-15+80°F)	1500	6.4	152	3±2°C (5.5±3.6 °F)	2±1°C (3.6±1.8 °F)	50°C (120°F)
KRA-1001552000	KUA-1001552000	-10+15°C (15-60°F)	1500	6.4	152	3±2°C (5.5±3.6 °F)	2±1°C (3.6±1.8 °F)	50°C (120°F)
KRA0000502000	KUA0000502000	0-50°C (32-120°F)	1500	6.4	152	3±2°C (5.5±3.6 °F)	2±1°C (3.6±1.8 °F)	60°C (140°F)
KRA0000705200	KUA0000705200	0-70°C (32-160°F)	1500	4.8	130	5±3°C (9±5.4°F)	3±2°C (5.5±3.6 °F)	160°C (320°F)
KRA0000701200	KUA0000701200	0-70°C (32-160°F)	3000	4.8	130	5±3°C (9±5.4°F)	3±2°C (5.5±3.6 °F)	160°C (320°F)
KRA0200905000	KUA0200905000	20-90°C (70-195°F)	1500	4.8	130	5±3°C (9±5.4°F)	3±2°C (5.5±3.6 °F)	160°C (320°F)
KRA0200901000	KUA0200901000	20-90°C (70-195°F)	3000	4.8	130	5±3°C (9±5.4°F)	3±2°C (5.5±3.6 °F)	160°C (320°F)
KRA0101505000	KUA0101505000	10-150°C (50-300°F)	1500	4.8	130	5±3°C (9±5.4°F)	3±2°C (5.5±3.6 °F)	160°C (320°F)
KRA0101501000	KUA0101501000	10-150°C (50-300°F)	3000	4.8	130	5±3°C (9±5.4°F)	3±2°C (5.5±3.6 °F)	160°C (320°F)
KRA0802000100	KUA0802000100	80-200°C (175-390°F)	1500	4	100	10±4°C (18±7°F)	7±3°C (12.5±5.4 °F)	320°C (610°F)
KRA0503000100	KUA0503000100	50-300°C (120-570°F)	1500	4	100	10±4°C (18±7°F)	7±3°C (12.5±5.4 °F)	320°C (610°F)
KRA0104507000	KUA0104507000	10-450°C (50-840°F)	1500	4.8	120	20±6°C (36±11°F)	12±4°C (22±7 °F)	760°C (1400°F)
KRA0104509000	KUA0104509000	10-450°C (50-840°F)	3000	4.8	120	20±6°C (36±11°F)	12±4°C (22±7 °F)	760°C (1400°F)
KRA0605007000	KUA0605007000	60-500°C (140-930°F)	1500	4.8	120	20±6°C (36±11°F)	12±4°C (22±7 °F)	760°C (1400°F)
KRA0605009000	KUA0605009000	60-500°C (140-930°F)	3000	4.8	120	20±6°C (36±11°F)	12±4°C (22±7 °F)	760°C (1400°F)
KRA1806007000	KUA1806007000	180-600°C (360-1110°F)	1500	4.8	120	20±6°C (36±11°F)	12±4°C (22±7 °F)	760°C (1400°F)
KRA1806009000	KUA1806009000	180-600°C (360-1110°F)	3000	4.8	120	20±6°C (36±11°F)	12±4°C (22±7 °F)	760°C (1400°F)
KRA2807007000	KUA2807007000	280-700°C (540-1290°F)	1500	3	300	20±6°C (36±11°F)	12±4°C (22±7 °F)	760°C (1400°F)

Main references

These thermostats are also available with screw driver adjustment, 20 or 30 mm shaft length Caution: Bulbs and capillaries of ranges higher than 300°C are filled with sodium potassium eutectic. If they leak or are broken this liquid is flammable if in contact with water

products and componen °C Printed knobs -25+25°C -10+15°C 0-50°C 0-70°C 20-90°C 10-150°C 50-300°C 10-450°C 180-400°C



PC + Santoprene Black ABS Chrome plated ABS Material Many other knobs are available, see the full knob list at the end of this catalogue.

his catalogue are made by Ultimheat alliance members.

280-700°C

60-500°C

Black PA66

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr

Stainless steel

## 8H type: Single pole high rating (30A) bulb and capillary thermostats

#### DIMENSIONS





#### **TECHNICAL FEATURES**

Applications: High rating single pole control, for catering equipment, domestic heaters,

Housing dimensions: 61 x 42 x 39.5 mm (without the terminals)

Material: metal /ceramic housing, stainless steel bulb and capillary. Capillary minimum bending radius 5 mm. 150 mm PVC sleeve on capillary

Temperature sensing element: liquid filled bulb and capillary. Special capillary length from 300 mm to 3000 mm on request (MOQ apply)

Terminals: 2 screws, UNC 8-32

Adjustment: dia. 6,35 mm (1/4") shaft, 11.5 mm length, 270° mechanical rotation other lengths, rotation or fixed setting available on request (MOQ apply). Mounting: front bracket with 4 tapped holes (#6-32 UNC-2B), 33.3 and 44.4 mm distance

Rating: 30A 250/400VAC, resistive

Contacts: 1 normally closed snap action contacts, double break, open on rise.

Option: back fixing bracket

Max ambient temperature on housing: 85°C/185°F

Accessories: dia. 50 mm knobs printed in °C or °F

Approvals: comply with EN 60730-1 and EN 60730-2 standards

#### **Main references**

References	Temperature range (°C/°F)	Capillary length (mm)	Bulb diameter (mm)	Bulb length (mm)	Differential (°C/°F)	Max temperature on bulb (°C/°F)
8HQ004040AO6A001	4-40°C (40-105°F)	1500	6	215	4±2°C/7±3.6 °F)	43°C/110°F
8HQ030090AO6A001	30-90°C (85-195°F)	1500	6	130	5±3(41±37.4°F)	100°C/212°F
8HQ030110AO6A001	30-110°C (85-230°F)	1500	6	120	14±3/57.2±37.4°F)	250°C/482°F
8HQ050200AO6A001	50-200°C (120-390°F)	1500	6	75	17±3/62.6±37.4°F)	250°C/482°F
8HQ050000AO6A001	50-300°C (120-570°F)	1500	6	75	17±3/62.6±37.4°F)	310°C/590°F



## 8J type: double pole high rating (30A) bulb and capillary thermostats

#### DIMENSIONS





#### **TECHNICAL FEATURES**

Applications: High rating single pole control, for catering equipment, domestic heaters,

Housing dimensions: 104 x 55 x 48 mm

Material: metal /ceramic housing, stainless steel bulb and capillary. Capillary minimum bending radius 5 mm. 150 mm PVC sleeve on capillary

Temperature sensing element: liquid filled bulb and capillary. Special capillary length from 300 mm to 3000 mm on request (MOQ apply)

Terminals: 2 screws, UNC 10-32

Adjustment: dia. 6,35 mm (1/4") shaft, 11.5 mm length, 270° mechanical rotation other lengths, rotation or fixed setting available on request (MOQ apply). Mounting: front bracket with 4 tapped holes (#6-32 UNC-2B), 33.3 and 44.4 mm distance

Rating: 30A 250/400VAC, resistive

Contacts: 2 normally closed snap action contacts, double break, open on rise.

Option: back mounting bracket

Max ambient temperature on housing: 85°C

Accessories: dia. 50 mm knobs printed in °C or °F

Approvals: comply with EN 60730-1 and EN 60730-2 standards

#### **Main references**

References	Temperature range (°C/°F)	Capillary length (mm)	Bulb diameter (mm)	Bulb length (mm)	Differential (°C/°F)	Max temperature on bulb (°C/°F)
8JQ004040AO6A001	4-40°C (40-105°F)	1500	6	215	4±2°C /7±3.6 °F)	43°C/110°F
8JQ030090AO6A001	30-90°C (85-195°F)	1500	6	130	5±3(41±37.4°F)	100°C/212°F
8JQ030110AO6A001	30-110°C (85-230°F)	1500	6	120	14±3/57.2±37.4°F)	250°C/482°F
8JQ050200AO6A001	50-200°C (120-390°F)	1500	6	75	17±3/62.6±37.4°F)	250°C/482°F
8JQ050000AO6A001	50-300°C (120-570°F)	1500	6	75	17±3/62.6±37.4°F)	310°C/590°F



Many other knobs are available, see the full knob list at the end of this catalogue.

his catalogue are made by Ultimheat alliance members.

## Type 8C 3 pole control thermostats

#### DIMENSIONS



#### **TECHNICAL FEATURES**

Housing dimensions: 46 x 50 x 45 mm (without terminals) Bulb and capillary: stainless steel, capillary length 250mm or 1500 mm, 150 mm long PVC sleeve on capillary. Capillary minimum bending radius 5 mm. Temperature sensing element: liquid filled bulb and capillary.

Terminals: 6.35 x 0.8 quick connect terminals .M4 screws also available on request.

Adjustment: Dia. 6 mm shaft with 4.6 mm flat, (other lengths or fixed setting available on request).

Mounting: Front bracket with 2 xM4 threads, 28 mm distance

Rating: 3 x 16A(4) 250VAC, 10A 400VAC

Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

Contacts: 3 x ST with snap action contact, 3PDT available on request



#### Main references

Reference	Temperature range (°C/°F)	Capillary length (mm)	Bulb diameter (mm)	Bulb length (mm)	Differential (°C/°F)	Max temperature on bulb (°C/°F)
8CB-35035AO60001	-35+35°C (-30+95°F)	1500	6	95	4±2°C/7±3.6 °F)	50°C/122°F
8CB-35035AA60001	-35+35°C (-30+95°F)	250	6	95	4±2°C/7±3.6 °F)	50°C/122°F
8CB004040AO60001	4-40°C (40-105°F)	1500	6	160	4±2°C/7±3.6 °F)	50°C/122°F
8CB004040AA60001	4-40°C (40-105°F)	250	6	160	4±2°C/7±3.6 °F)	50°C/122°F
8CB030090AO60001	30-90°C (85-195°F)	1500	6	86	6±3°C/42.8±37.4°F	110°C/230°F
8CB030110AO60001	30-110°C (85-230°F)	1500	6	70	6±3°C/42.8±37.4°F	130°C/266°F
8CB050200AO60001	50-200°C (120-390°F)	1500	6	57	13±4°C/55.4±39.2°F	220°C/428°F
8CB050300AO30001	50-300°C (120-570°F)	1500	3	165	15±5°C/59±41°F	320°C/608°F

#### °C Printing

	CPrinting								
-35+3	5°C	4-40°C	30-90°C	30-110°C	50-200°C		50-300°C		
						)			
66MZ006-3	50352FW	66MZ0060040402FW	66MZ0060300901FW	66MZ0060301101FW	66MZ00605020	01FW	66MZ0060503001FW		
			°F Pri	nting					
30+9	5°F	40-105°F	85-195°F	85-230°F	120-390°F		120-570°F		
66MZ006-3	350352FX	66MZ0060040402FX	66MZ0060300901FX	66MZ0060301101FX	66MZ00605020	001FX	66MZ0060503001FX		
	Soft grip knob and bezel dimensions								
	1200		Ø42mm	Ø42mm	1.700		Ø60mm Ø42mm		

Dimensions	06mm 06mm 06mm	28mm 28mm (x4) 28mm (x4) 28mm 08mm 08mm 08mm	28mm 28mm (x4) 28mm 04.5mm (x4) 28mm 06mm 047mm	042mm 042mm 28mm 04.5mm (x4) 4.5mm
	And			
References	66MZ	66EN1	66EN3	66EN2
Material	PC +Santoprene	Black ABS	Chrome plated ABS	Stainless steel
Many other kno	obs are available, see the full knob list at	the end of this catalogue.		

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr



JP

## SPDT Bimetal rod thermostats, SR and SU types

DIMENSIONS



Mounting accessories are described in the last section of this catalogue.

## SPDT Bimetal rod thermostats with dead zone, VR and VU types



t

49

his catalogue are made by Ultimheat alliance members.

, products and componen

Unless exceptionally specified by this logo

products and componer

◀

Unless exceptionally specified by this logo



#### Applications: temperature control of liquid and gas, with DPST or SPDT contact Sensing element: Bimetal rod, 304 stainless steel, dia. 9.5 mm, fast thermal response Housing: no housing in this model, See catalogue N°2 for this product with aluminum housing Standard temperature setting ranges: -10+130°C, 15-95°C, 25-165°C. Other temperature ranges on request. Differential:

• Standard: 15°C with 200 mm rod, 10°C with 300 mm rod

• Reduced: 3°C with 200 mm rod, 2°C with 300 mm rod

Set point adjustment: screw driver, with temperature printed dial

Mounting: inside pocket, locked by clips

**Contact:** DPNC or 1xNC + 1 x NO

Rating: standard differential 15(4)A, 250/400VAC Reduced differential: 4(1)A 250VAC

Ambient temperature: -30+100°C on thermostat body, and Max dial temperature value+50°C on rod

Main references							
Set point adjustment range (°C)	Rod length (mm)	References with DPNC contact, standard differential	References with DPNC contact, reduced differential	References with 1 x NC + 1 x NO contact, standard differential	References with 1 x NC + 1 x NO contact, reduced differential		
-10+130	200	1BA-10130B200	1CA-10130B200	1RA-10130B200	1UA-10130B200		
+15+95	200	1BA015095A200	1CA015095A200	1RA015095A200	1UA015095A200		
+15+95	300	1BA015095C300	1CA015095C300	1RA015095C300	1UA015095C300		
+25+165	200	1BA025165B200	1CA025165B200	1RA025165B200	1UA025165B200		
A	· · · · · · · · / · · · · · · · · · · ·	برجاح والارتجاب والارتجا					

#### Accessories (not included in the thermostat, must be ordered separately)

Pocket, nickel plated copper alloy, length 200mm or 300 mm



Pocket clamping





JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr

## DIMENSIONS

# **Electronic thermostats**





## Electronic thermostat, multi range, control and manual reset action, for incorporation, Type: 2PE2N6

can be modified without prior advice

Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and (



products and components in this catalogue are made by Ultimheat alliance members. 1 Unless exceptionally specified by this logo

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr

53

## Digital display electronic controller, Din Rail mounting, ON-OFF, Type: 2DNAP6F



This electronic temperature controller with the simplest and the most instinctive setting by end user was designed for easy incorporation inside cabinets with DIN rail mounting. It can be used by untrained operators.

It provides simple On Off action temperature control.

It is possible to set °C or °F display, heating or cooling relay output, decimal display, sensor type and temperature range by internal Dip switches (Without access by end user). Adjustment of maximum temperature can be set without need to open the control. Dimensions: 86.9 x 58 x 52.5 mm

Display: 31-1 digit LED. The fourth digit is used to display °C or °F, upon setting made. Set point setting: In normal use, the display shows measured temperature. Push "+" or "-" keys will display the set point value, and at that time it can be adjusted with "+" and "" keys. No action during 5 seconds will register the new set point value and bring back display to measured value. Temperature differential setting: In normal use, the display shows measured temperature. Push "D" key will display the differential value, at that time it can be adjusted with "+" and "" keys. Push "D" key will display the differential value, at that time it can be adjusted with "+" and "" keys. Push "D" again or no action during 5 seconds will register the new differential value and bring back display to measured value.

Action: On-OFF

Temperature sensor: Pt100 (2 or 3 wires) or NTC 10Kohms @25°C, B= 3380 (2 wires) Temperature sensor can be selected by a dip switch on circuit (No access to final user) Temperature sensor: Pt100 (2 or 3 wires) or NTC 10Kohms @25°C, B= 3380 (2 wires) Temperature sens Accuracy: +/-1% of scale Temperature adjustment ranges: - 30+120°C (-20+250°F), with 1° display - 30,0 to +40,0°C (-20,0 + 99,9°F), with 1/10° display - 30+400°C (-20+750°F), with 1° display - 30+400°C (-20+750°F), with 1° display - 30+400°C (-20+750°F), with 1° display Temperature range and decimal digit can be selected by a dip switch on circuit (No access to final user) Power supply: 90 to 240V, 50Hz or 60Hz

Relay output: SPNO, 16A250V res., 100.000 cycles. Output Led displays relay position.

Relay action: Heating or cooling, open or close on temperature rise output relay action can be selected by a dip switch on circuit (No access to final user) °C or °F display: can be selected by a dip switch on circuit (No access to final user) Maximum possible set point adjustment by user: Push "D" button more than 10 seconds, display shows the maximum temperature that can be set by user. Then it is possible to adjust this value with "+" and "-", push again on "D" or do nothing during 5 seconds will register the maximum possible setting value and control will comes back to measured valued.

Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

Ambiant: -20+60°C, 10-90% RH

## Power: <4W Fail safe safety:

- If no power supply, relay output contact will open - If Pt100 sensor or NTC is broken or not connected properly, relay output contact will open and display will show "EEE" - If measured temperature is higher than allowed by the set range, display will show "HHH" - If measured temperature is lower than -30,0°C or -20,0°F, display will show "LLL"

**Electrical connections:** 

Power input: Neutral, phase, ground, with 2.5 mm<sup>2</sup> terminals
 Power output: Neutral, phase, ground, with 2.5 mm<sup>2</sup> terminals for direct connection to the load.
 Temperature sensor: three 2.5 mm<sup>2</sup> screw terminal
 One removable jumper provides a potential free relay output for applications needing a separate circuit for relay, external timer or other.
 Internal parameters setting: Process is given on request to approved distributors. This allows to store only one product and set parameters upon end user request.
 Standards: Comply with EMC (CE), ROHS and Reach

#### Main references

References	Temperature range	Sensor	Display	Relay Output
2DNAP6FA	-30+120°C	NTC	888 <mark>C</mark> (°C)	Heating
2DNAP6FB	-20+250°F	NTC	888 <mark>F</mark> (°F)	Heating
2DNAP6FC	-30+120°C	NTC	888 <mark>C</mark> (°C)	Cooling
2DNAP6FD	-20+250°F	NTC	888 <mark>F</mark> (°F)	Cooling
2DNAP6FE	-30, 0 to +40, 0°C	Pt100	88.8 <mark>C</mark> (°C)	Heating
2DNAP6FF	-20,0 + 99.9°F	Pt100	88.8 <mark>F</mark> (°F)	Heating
2DNAP6FG	-30, 0 to +40, 0°C	Pt100	88.8 <mark>C</mark> (°C)	Cooling
2DNAP6FH	-20,0 + 99.9°F	Pt100	88.8 <mark>F</mark> (°F)	Cooling
2DNAP6FI	-30+400°C	Pt100	888 <mark>C</mark> (°C)	Heating
2DNAP6FJ	-20+750°F	Pt100	888 <mark>F</mark> (°F)	Heating
2DNAP6FK	-30+400°C	Pt100	888 <mark>C</mark> (°C)	Cooling
2DNAP6FL	-20+750°F	Pt100	888 <mark>F</mark> (°F)	Cooling
2DNAP6F0		No internal setting made, sold	only to approved distributors.	

#### No internal setting made, sold only to approved distributors. Standard temperature sensors (For more models see catalogue N°3



# Manual reset thermostats and thermal cut-outs





Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

### Type 8I 3 pole combination control thermostat

#### DIMENSIONS



#### **TECHNICAL FEATURES**

Housing dimensions: 60 x 54 x 48 mm (without terminals)

Bulb and capillary: stainless steel, capillary length 1500 mm, 150 mm long PVC sleeve on capillary. Capillary minimum bending radius 5 mm.

Temperature sensing element: liquid filled bulb and capillary.

Terminals: 6.35 x 0.8 quick connect terminals. M4 screws also available on request.

Adjustment: Dia. 6 mm shaft with 4.6 mm flat, (other lengths or fixed setting available on request).

Manual reset: fail safe, fixed setting, front access reset button

Fail safe contact action by low temperature: Temperatures under -15°C (5°F) will trigger the manual reset.

Mounting: Front bracket with 2 x M4 threads, 28 mm distance

Rating: 3 x16A 250VAC, 10A 400VAC (res.)

Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

Contacts: 3 poles ST (snap action contact)

#### **Main references Bulb Bulb length** Differential Max temperature Temperature Capillaries Manual reset diameter Reference length (mm) on bulbs (°C) range (°C) (mm) (°C) temperature (mm)170°C/ 110°C+0/-9 30-85°C/ 94 (E1) 12 ±6°C/ 338°F (E1) 8IC085110AO60001 1500 6 86-185°F 129 (E2) 53.6±42.8°F 140°C/ 230°F+0/-48.2 284°F (E2)

Other calibration values, ask our engineering department.

•		СΡ	rinting	°F Printing	
		30	-85°C	85-185°F	
-		66MZ006	0300854FW	66MZ0060300854FX	
			66MZ Soft grip knob	and bezel dimensions	
D	Dimensions	06mm 06mm 4.6mm	28mm 28mm (x4) 28mm (x4) 28mm 28mm 04.5mm 04.5mm	28mm (x4) 28mm (x4) 28mm (x4) 28mm (x4) 28mm (x4) 28mm (x4) 28mm	060mm 042mm 28mm 04.5mm (x4) 4.5mm
		and the second	$(\mathfrak{B})$		
	References	66MZ	66EN1	66EN3	66EN2
	Material	PC +Santoprene obs are available, see the full knoblist at t	Black ABS	Chrome plated ABS	Stainless steel
Ma	any other kno	bbs are available, see the full knoblist at t	the end of this catalogue.		

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr

57

## Type 8L SPNC manual reset high limit, fail safe

#### DIMENSIONS





Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

#### **TECHNICAL FEATURES**

Housing dimensions: 43 x 35 x 29 mm (without terminals)

Bulb and capillary: stainless steel, capillary length 250mm or 1500 mm, 150 mm long PVC sleeve on capillary. Capillary minimum bending radius 5 mm.

Temperature sensing element: liquid filled bulb and capillary.

Terminals: 6.35 x 0.8 guick connect terminals (M4 screws also available on request),

Adjustment: fixed setting, sealed

Manual reset: fail safe, fixed setting, front access reset button

Fail safe contact action by low temperature: Temperatures under -10°C (14°F) will trigger the manual reset.

Mounting: Front bushing, M10 x1 thread

Rating: 16A 250/400VAC

**Contacts:** SPST (snap action contact)

Max ambient temperature on body: 150°C (302°F)

Main references								
Reference	Calibration Temperature (°C/°F)	Minimum resettable temperature (°C/°F)	Capillary length (mm)	Bulb diameter (mm)	Bulb length (mm)	Max temperature on bulb (°C/°F)		
8L0080105AO61001	80±8°C/ 176±46.4°F	52°C/125.6°F	1500	6	77	105°C/239°F		
8L0080105AA61001	80±8°C/ 176±46.4°F	52°C/125.6°F	250	6	77	105°C/239°F		
8L0090115AO61001	90±8°C/ 194±46.4°F	60°C/140°F	1500	6	77	115°C/239°F		
8L0110135AO61001	110±8°C/ 230±46.4°F	75°C/167°F	1500	6	77	135°C/275°F		
8L0130155AO61001	130±8°C/ 266±46.4°F	80°C/176°F	1500	6	74	155°C/311°F		
8L0150175AO61001	150±8°C/ 302±46.4°F	95°C/203°F	1500	6	74	175°C/347°F		
8L0175200AO41001	175±8°C/ 347±46.4°F	115°C/239°F	1500	4	95	200°C/392°F		
8L0220245AO41001	220±11°C/ 428±51.8°F	140°C/284°F	1500	4	90	245°C/473°F		
8L0270295AO41001	270±13°C/ 518±51.8°F	160°C/230°F	1500	4	85	295°C/617°F		
8L0300325AO41001	300±15°C/ 572±59°F	160°C/230°F	1500	4	82	325°C/617°F		
Other temperatures an	Other temperatures and capillary lengths on request.							

58

## Type KX SPDT manual reset high limit, adjustable, commercial type

#### DIMENSIONS





#### **TECHNICAL FEATURES**

**Housing dimensions:** 79 x 53 x 36 mm (without terminals)

**Bulb and capillary:** Copper for temperature ranges up to 50°C(120°F), stainless steel above ,capillary length 1500 mm or 3000 mm. Capillary minimum bending radius 5mm.

Temperature sensing element: Liquid filled bulb and capillary.

Terminals: 6.35 x 0.8 quick connect terminals (M4 screws also available on request),

Adjustment: Dia. 6 mm shaft with 4.6 mm flat, (other lengths or fixed setting available on request).

Mounting: Front bracket with 2 xM4 threads, 28 mm distance

Rating: 15A (1/4 HP) 250VAC, 15A 400V res.

Contacts: SPDT (snap action contact)

on these data sheets are for guidance only and can be modified without prior advice

Because of permanent improvement of our products, drawings, descriptions, features used

Electrical life: >100.000 cycles at nominal rating

#### Main references Max **Temperature range Bulb diameter Bulb length Reset Differential** Capillary Reference temperature (°C/°F) length (mm) (°C/°F) (mm) (mm) on bulb (°C/°F) KXC-250252200 -25+25°C (-15+80°F) 1500 152 6±2°C/42.8±35.6°F 50°C (120°F) 6.4 KXC-1001552000 -10+15°C (15-60°F) 6±2°C/42.8±35.6°F 1500 6.4 152 50°C (120°F) KXC0000502000 0-50°C (32-120°F) 6.4 152 6±2°C/42.8±35.6°F 1500 60°C (140°F) KXC0000705200 0-70°C (32-160°F) 4.8 120 10±3°C/50±37.4°F 160°C (320°F) 1500 120 10±3°C/50±37.4°F 160°C (320°F) KXC0000701200 0-70°C (32-160°F) 3000 4.8 KXC0200905000 20-90°C (70-195°F) 1500 4.8 120 10±3°C/50±37.4°F 160°C (320°F) KXC0200901000 20-90°C (70-195°F) 3000 4.8 120 10±3°C/50±37.4°F 160°C (320°F) KXC0101505000 10-150°C (50-300°F) 1500 4.8 120 10±3°C/50±37.4°F 160°C (320°F) 4.8 120 10±3°C/50±37.4°F KXC0101501000 10-150°C (50-300°F) 3000 160°C (320°F) 320°C (610°F) KXC0802000100 1500 4 100 20±4°C/68±39.2°F 80-200°C (175-390°F) KXC0503000100 50-300°C (120-570°F) 1500 4 100 20±4°C/68±39.2°F 320°C (610°F) KXC0104507000 10-450°C (50-840°F) 1500 4.8 120 40±6°C/104±42.8°F 760°C (1400°F) 4.8 120 40±6°C/104±42.8°F KXC0104509000 10-450°C (50-840°F) 3000 760°C (1400°F) 40±6°C/104±42.8°F KXC0605007000 60-500°C (140-930°F) 1500 4.8 120 760°C (1400°F) KXC0605009000 60-500°C (140-930°F) 3000 4.8 120 40±6°C/104±42.8°F 760°C (1400°F) 4.8 KXC1806007000 180-600°C (360-1110°F) 1500 120 40±6°C/104±42.8°F 760°C (1400°F) 120 KXC1806009000 180-600°C (360-1110°F) 3000 4.8 40±6°C/104±42.8°F 760°C (1400°F) KXC2807008000 280-700°C (540-1290°F) 1500 3 300 40±6°C/104±42.8°F 760°C (1400°F)

Caution: Bulbs and capillaries of ranges higher than 300°C are filled with sodium potassium eutectic. If they leak or are broken this liquid is flammable if in contact with water



# Single pole manual reset disc thermostat, 1/2", snap action. 16A 250V Type 4R05



References	Open (°C/°F)	Tolerance (°C/°F)	Bracket style	Bracket material	Terminal style	Terminal to bracket hole angle
4R05EJ050RMDCSV047	50°C/122°F	±4°C/±39.2°F	1	SS	G	N/A
4R05EJ055RMCCSVF44	55°C/131°F	±3°C/±37.4°F	4	SS	G	45°
4R05EJ055RMCCSVF41	55°C/131°F	±3°C/±37.4°F	4	SS	G	135°
4R05EJ065RMDCSVF44	65°C/149°F	±4°C/±39.2°F	4	SS	G	45°
4R05EJ070RMDCSVM47	70°C/158°F	±4°C/±39.2°F	2	SS	G	N/A
4R05EJ075RMDCSVM47	75°C/167°F	±4°C/±39.2°F	2	SS	G	N/A
4R05EJ075RMDCSVF44	75°C/167°F	±4°C/±39.2°F	4	SS	G	45°
4R05EJ085RMDCSVF44	85°C/185°F	±4°C/±39.2°F	4	SS	G	45°
4R05EJ090RMDL6VM37	90°C/194°F	±4°C/±39.2°F	2	AL	А	N/A
4R05EJ090RMDCSVF44	90°C/194°F	±4°C/±39.2°F	4	SS	G	45°
4R05EJ120RMDCSVF44	120°C/248°F	±4°C/±39.2°F	4	SS	G	45°
4R05NJ150RMEL6HM37	150°C/302°F	±6°C/±42.8°F	2	AL	В	N/A



## 3 pole manual reset disc thermostats 4C types

DIMENSIONS





#### **TECHNICAL FEATURES**

Applications: Temperature limit of heaters, instant water heaters, saunas steam generators, industrial heaters Housing dimensions: diameter 45mm, height 20mm (28mm with terminals), Body material: high temperature PPS Temperature sensing element: Bimetal disc Terminals: 6.35 x 0.8mm quick connect

Set point temperature range: +20 to +180°C (Factory fixed setting only)

Mounting: surface mounting fixed bracket, 2 holes 4.4 x 6.4mm, 60 mm distance

Rating: 3 x 16A 250VAC, 3 x 10A 400VAC, resistive (10000 cycles)

3 x 25A 250VAC, 3 x 16A 400VAC (300 cycles)

Contact: 3 snap action contacts, double break, open on temperature rise.

Max ambient temperature: 180°C

Approvals: comply with EN 60730-1 and EN 60730-2 standards (CE mark)

Main references							
References	Operating Temperature (°C/°F)	Tolerance (°C/°F)	References	Operating Temperature (°C/°F)	Tolerance (°C/°F)		
4C504T070RMEM60D	70°C/158°F	±4°C/±39.2°F	4C504T105RMEM60D	105°C/221°F	±6°C/±42.8°F		
4C504T075RMEM60D	75°C/167°F	±4°C/±39.2°F	4C504T110RMEM60D	110°C/230°F	±6°C/±42.8°F		
4C504T080RMEM60D	80°C/176°F	±5°C/±41°F	4C504T120RMEM60D	120°C/248°F	±6°C/±42.8°F		
4C504T085RMEM60D	85°C/185°F	±5°C/±41°F	4C504T130RMEM60D	130°C/266°F	±6°C/±42.8°F		
4C504T090RMEM60D	90°C/194°F	±5°C/±41°F	4C504T140RMEM60D	140°F/284°F	±7°C/±44.6°F		
4C504T095RMEM60D	95°C/203°F	±5°C/±41°F	4C504T150RMGM60D	150°C/302°F	±7°C/±44.6°F		
4C504T100RMEM60D	100°C/212°C	±5°C/±41°F	4C504T160RMEM60D	160°C/320°F	±7°C/±44.6°F		







Long distance manual reset rods			
	Poforonco		

 114
 664CLR114

 30
 664CLR030

Other lenght on request



## Type 8X DPNC manual reset high limit, fail safe

#### DIMENSIONS



#### **TECHNICAL FEATURES**

Housing dimensions: 43 x 35 x 29 mm (without terminals and diaphragm)

Capillary: copper, capillary length 250mm or 900 mm, 150 mm long PVC sleeve on capillary. Capillary minimum bending radius 5 mm.

For technical reasons, we do not recommend to use capillary length longer than 900 mm. **Bulb:** copper, corkscrew type for temperatures from 60 to 130°C(140 to 266°F), tubular dia 6 mm from 130°C to 170°C(266 to 338°F).

Temperature sensing element: Liquid-filled thermostatic assembly whose boiling causes tripping of the contact. Therefore, unlike liquid filled systems, these thermostats are sensitive to atmospheric pressure, and their reaction time is slower. Terminals: 6.35 x 0.8 quick connect terminals Adjustment: fixed setting

Mounting: Front bushing, with M10x1

Manual reset: fail safe action, front access button

Rating: 20A 250VAC Contacts: DPST (snap action contact)

Max ambient temperature on head: 125°C

#### Main references

Reference	Calibration Temperature (°C/°F)	Minimum resettable temperature (°C/°F)	Capillary length (mm)	Bulb diameter (mm)	Bulb length (mm)	Max temperature on bulb (°C/°F)
8X0060090Cl61001	60±5°C/140±41°F	20°C/68°F	900	6	50	90°C/194°F
8X0060090CA61001	60±5°C/140±41°F	20°C/68°F	250	6	50	90°C/194°F
8X0070100Cl61001	70±5°C/158±41°F	30°C/86°F	900	6	50	100°C/212°F
8X0080110Cl61001	80±5°C/176±41°F	40°C/104°F	900	6	50	110°C/230°F
8X0090120Cl61001	90±5°C/194±41°F	50°C/122°F	900	6	50	120°C/248°F
8X0110140Cl61001	110±5°C/230±41°F	70°C/158°F	900	6	50	140°C/284°F
8X0130160Cl61001	130±6°C/266±42.8°F	90°C/194°F	900	6	60 <b>*</b>	160°C/320°F
8X0150180Cl61001	150±7°C/302±44.6°F	110°C/230°F	900	6	60*	180°C/356°F
8X0170200Cl61001	170±7°C/338±44.6°F	130°C/266°F	900	6	60*	200°C/392°F
* Cylinder bulb						

y Ultimheat alliance members.

62

#### DIMENSIONS



#### **TECHNICAL FEATURES**

#### Housing dimensions: dia 45 x 44.3 mm

features used on these data sheets are for guidance only and can be modified without prior advice

descriptions,

Because of permanent improvement of our products, drawings,

Capillary: copper, capillary length 250mm or 900 mm, 150 mm long PVC sleeve on capillary. Capillary minimum bending radius 5 mm.

For technical reasons, we do not recommend to use capillary length longer than 900 mm.

Bulb: Copper, corkscrew type for temperatures from 60 to 130°C(140 to 266°F), tubular dia 6 mm from 130°C to 170°C (266 to 338°F).

**Temperature sensing element:** Liquid-filled thermostatic assembly whose boiling causes tripping of the contact. Therefore, unlike liquid filled systems, these thermostats are sensitive to atmospheric pressure, and their reaction time is slower. **Terminals:** 6.35 x 0.8 guick connect terminals Adjustment: fixed setting

Mounting: Backside legs, 2 M4 screws, holes distance 60 mm

Manual reset: fail safe action, center button

Rating: 3 x 16A 250VAC, 3 x 10A 400VAC, resistive (10000 cycles)

3 x 25A 250VAC, 3 x 16A 400VAC (300 cycles)

Contacts: ST, open on temperature rise (snap action contact)

Max ambient temperature on head: 150°C(302°F)

Main references							
Reference	Calibration Temperature (°C/°F)	Minimum resettable temperature (°C/°F)	Capillary length (mm)	Bulb diameter (mm)	Bulb length (mm)	Max temperature on bulb (°C/°F)	
820060090Cl61001	60±5°C/140±41°F	20°C/68°F	900	6	50	90°C/194°F	
820060090CA61001	60±5°C/140±41°F	20°C/68°F	250	6	50	90°C/194°F	
820070100Cl61001	70±5°C/158±41°F	30°C/86°F	900	6	50	100°C/212°F	
820080110Cl61001	80±5°C/176±41°F	40°C/104°F	900	6	50	110°C/230°F	
820090120Cl61001	90±5°C/194±41°F	50°C/122°F	900	6	50	120°C/248°F	
820110140Cl61001	110±5°C/230±41°F	70°C/158°F	900	6	50	140°C/284°F	
820130160Cl61001	130±6°C/266±42.8°F	90°C/194°F	900	6	60*	160°C/320°F	
820150180Cl61001	150±7°C/302±44.6°F	110°C/230°F	900	6	60*	180°C/356°F	
820170200Cl61001	170±7°C/338±44.6°F	130°C/266°F	900	6	60*	200°C/392°F	

Cylinder bulb



#### Long distance manual reset rods

L	Reference		
114	664CLR114		
30	664CLR030		
Other lenght on request			

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr



┚╴

## Manual reset rod thermostat, DPST and SPDT, types 1D and 1X



#### **TECHNICAL FEATURES**

Applications: high limit manual reset on liquid and gas, with DPNC or SPDT contact

Sensing element: Bimetal rod, 304 stainless steel, dia. 9.5 mm, fast thermal response

Housing: no housing in this model, See Y1 range for this product with aluminum housing

Standard temperature setting ranges: -10+130°C, 15-95°C, 25-165°C. Other temperature ranges on request.

Set point adjustment: screw driver, with temperature printed dial

Manual reset: with un-protected front button

Mounting: inside pocket, locked by clips Contact: DPNC or 1 x NC + 1 x NO

Rating: 15(4)A, 250/400VAC

Ambient temperature: -30+100°C(-22 +212°F) on thermostat body, and max dial temperature value+50°C(122°F) on rod

Main references						
Set point adjustment range (°C/°F)	Rod length (mm)	References with DPNC contact	References with 1 x NC + 1 x NO contact,			
-10+130°C/+14+266°F	200	1DA-10130B200	1XA-10130B200			
+15+95/+59+203°F	200	1DA015095A200	1XA015095A200			
+15+95/+59+203°F	300	1DA015095C300	1XA015095C300			
+25+165/+77+329°F	200	1DA025165B200	1XA025165B200			

#### Accessories (not included in the thermostat, must be ordered separately)

Pocket, nickel plated copper alloy, length 200mm or 300 mm

**Pocket clamping** 



3

3

4

y Ultimheat alliance members.

64

## Thermal cut outs, 10 and 16A 250V, axial wires, type 5MA3



· Choose TCO temperature fuse which electrical insulation will not be effected by equipment overheat. TCO replacement must be made by exactly the same model of the same supplier

guidance only and can be modified without prior advice

on these data sheets are for

used

Ser

drawings,

Cts,

produ

Because of permanent improvement of our

#### Main references

Wall Telefices							
Reference with 10A rating	Reference with 16A rating	Rated functioning temperature °C/°F (Tf)	Holding temperature °C/°F (Th)	Maximum temperature °C/°F (Tm)			
5MA3SPF070019340	5MA3SPF070H19340	73°C/163.4°F	45°C/113°F	115°C/239°F			
5MA3SPF077019340	5MA3SPF077H19340	79°C/174.2°F	52°C/125.6°F	125°C/257°F			
5MA3SPF084019340	5MA3SPF084H19340	85°C/185°F	57°C/134.6°F	125°C/257°F			
5MA3SPF091019340	5MA3SPF091H19340	94°C/201.2°F	66°C/150.8°C	140°C/284°F			
5MA3SPF096019340	5MA3SPF096H19340	99°C/210.2°F	71°C/159.8°F	140°C/284°F			
5MA3SPF106019340	5MA3SPF106H19340	108°C/226.4°F	77°C/170.6°F	145°C/293°F			
5MA3SPF109019340	5MA3SPF109H19340	113°C/235.4°F	84°C/183.2°F	150°C/302°F			
5MA3SPF121019340	5MA3SPF121H19340	122°C/251.6°F	94°C/201.2°F	175°C/347°F			
5MA3SPF129019340	5MA3SPF129H19340	133°C/271.4°F	101°C/213.8°F	175°C/347°F			
5MA3SPF139019340	5MA3SPF139H19340	142°C/287.6°F	114°C/237.2°F	185°C/365°F			
5MA3SPF152019340	5MA3SPF152H19340	157°C/314.6°F	127°C/260.6°F	195°C/383°F			
5MA3SPF165019340	5MA3SPF165H19340	167°C/332.6°F	130°C/266°F	205°C/401°F			
5MA3SPF169019340	5MA3SPF169H19340	172°C/341.6°F	145°C/293°F	215°C/419°F			
5MA3SPF182019340	5MA3SPF182H19340	184°C/363.2°F	156°C/312.8°F	225°C/437°F			
5MA3SPF188019340	5MA3SPF188H19340	192°C/377.6°F	164°C/327.2°F	245°C/473°F			
5MA3SPF216019340	5MA3SPF216H19340	216°C/420.8°F	189°C/372.2°F	280°C/536°F			
5MA3SPF227019340	5MA3SPF227H19340	227°C/440.6°F	190°C/374°F	295°C/563°F			
5MA3SPF240019340	5MA3SPF240H19340	240°C/464°F	190°C/374°F	305°C/581°F			

## Type 5MA 3-F Wired thermal fuses, for insertion into 8.5 mm I.D. pockets

#### DIMENSIONS



#### **TECHNICAL FEATURES**

**Applications:** protection against overheating of equipment and heating elements **Fusible pellet:** organic compound

Mechanism: movable pellet actuated of a spring released by the fusion of the pellet

Protection: with electrical insulation silicone boot, dia. 8mm

Nominal current rating: 16A 250V

The nominal current rating is the maximum current the fuse can carry without opening or deteriorate when subjected to a temperature known as the "holding temperature" (Th) for a limited time

Holding temperature (Th): the fuse must not open or be destroyed when subjected to a temperature equal to Th-6 °C for a period of 168 hours under nominal voltage and current

**Rated functioning temperature (Tf):** It is the opening temperature of the fuse in a calibration oven, when subjected to a current less than 10 mA, when temperature rises at a speed of 0.5 to 1 °C / min. The opening temperature must not be lower than Tf-10 °C or above Tf under these conditions. This is the operating temperature Tf which is printed on the fuse and the protective sheath external of the leads.

of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

Maximum temperature (Tm): it is the maximum temperature withstood by the fuse after opening without losing its insulating and mechanical properties.

Insulation voltage between open contacts:  $\geq 500V$ 

Insulation resistance between open contacts:  $\geq 0.2 \text{ M}\Omega @ 500 \text{V}$ 

Lead lengths: 500 mm.

Leads: FEP 300V primary insulation, 1 mm<sup>2</sup> gauge (AWG18), in a polyolefin sheath.

In red: standard available temperatures

#### In red: standard available temperatures

Reference	Rated functioning temperature °C/°F (Tf)	Holding temperature °C/°F (Th)	Maximum temperature °C/°F (Tm)
5MA3SPF070F18500	73°C/163.4°F	45°C/113°F	115°C/239°F
5MA3SPF077F18500	79°C/174.2°F	52°C/125.6°F	125°C/257°F
5MA3SPF084F18500	85°C/185°F	57°C/134.6°F	125°C/257°F
5MA3SPF091F18500	94°C/201.2°F	66°C/150.8°C	140°C/284°F
5MA3SPF096F18500	99°C/210.2°F	71°C/159.8°F	140°C/284°F
5MA3SPF106F18500	108°C/226.4°F	77°C/170.6°F	145°C/293°F
5MA3SPF109F18500	113°C/235.4°F	84°C/183.2°F	150°C/302°F
5MA3SPF121F18500	122°C/251.6°F	94°C/201.2°F	175°C/347°F
5MA3SPF129F18500	133°C/271.4°F	101°C/213.8°F	175°C/347°F
5MA3SPF139F18500	142°C/287.6°F	114°C/237.2°F	185°C/365°F
5MA3SPF152F18500	157°C/314.6°F	127°C/260.6°F	195°C/383°F
5MA3SPF165F18500	167°C/332.6°F	130°C/266°F	205°C/401°F
5MA3SPF169F18500	172°C/341.6°F	145°C/293°F	215°C/419°F
5MA3SPF182F18500	184°C/363.2°F	156°C/312.8°F	225°C/437°F
5MA3SPF188F18500	192°C/377.6°F	164°C/327.2°F	245°C/473°F
5MA3SPF216F18500	216°C/420.8°F	189°C/372.2°F	280°C/536°F
5MA3SPF227F18500	227°C/440.6°F	190°C/374°F	295°C/563°F
5MA3SPF240F18500	240°C/464°F	190°C/374°F	305°C/581°F

# **Thermostat accessories**





## **Knobs for thermostats**



\*\* The complete reference is determined by other parameters such as plastic color, printing color, printing style etc.

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr

69

JPC

In some applications it may be necessary to limit the temperature maximum setting (or minimum) possible by the user. Some knobs that we have developed provide this option.





Because of permanent improvement of our products, drawings, descriptions, features used on these data sheets are for guidance only and can be modified without prior advice

JPC

## Dials, bezels and mounting boards



JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr

## **Knobs dials and brackets**



72

products and components in this catalogue are made by Ultimheat alliance members.

1

nless exceptionally specified by this logo

## **Pockets**

66DR12510021C000	66DL14P****	66DI12****	66DK12****	66DU****
		015 22387 015 00 005 00 000 000 000 000 00000 000 000 000 000 000 000 000 000 000 000	2300 22387 01500 000 000 100 100 100 100 1	1         10000         12000           1         1         1         0           1         1         1         0         0           1         1         1         0         0         0           1         1         1         1         0         10000           1         1000         15600         20000         12000         12000
PBT pocket, ½" NPT thread	Nickel plated brass pocket, ¼" BSPP thread. Available in various diameters and lengths	304 Stainless steel pocket, with M4 securing screw, ½"BSPP thread. Available in various diameters and lengths	Nickel plated brass pocket, ½" BSPT thread Available in various diameters and lengths	Stainless steel mechanical protection for wall mounting thermostat bulb or sensor

\*\*\*\* Many thermostat mounting accessories (pockets, flanges, fittings, coolers) have been developed for thermostats with enclosures, and can be used on thermostats for incorporation. See catalog No. 2 which gives all the possible references of these accessories

## Pockets grommets

Used to hold probes or electronic thermostat bulbs inside a pocket or a tube, while protecting them against the sharp edges of the tip Flammability: UL 94-V0 Hardness: 60 Shore A Color: black. Other colors available (MOQ apply)



Many silicone parts have been developed for thermostats with enclosures, and can be used on thermostats for incorporation. See catalog No. 2

## Flanges and fittings





JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr

73

## Thermostat boots

They are designed to protect thermostats against accidental contact or liquid ingress. They may, depending on the model, be filled with a resin or simply be glued or 

 They are designed to protect themselves 12.

 vulcanizedon their support

 Flammability: UL 94-V0

 Hardness: 60 Shore A

 Color: black or red depending on the model. Other colors are available. (MOQ apply).

 Participation of the model. Other colors are available. (MOQ apply).

 Participation of the model. Other colors are available. (MOQ apply).

 9BBJO1000SPH016A (F1) 9BBJO1000SPH018A (F6) F1 & ( Silicone boot for PT100, TCO or Silicone boot with cable retainer, for Bimetal thermostat silicone boot, for flexible silicone heaters, with cable retainer Disc thermostat silicone boot, for flexible silicone heaters Bimetal thermostat silicone boot, for flexible silicone heaters, with pilot ligh temperature limiters, with silicone RTV potting holes, for flexible silicone temperature limiters, with silicone RTV potting holes, for flexible silicone heaters heaters 9BBJO1000ELH025A 9BBJ01000ELH058A 9BBJ01000004015A 9BBJ01000004017A 9BBJO1000004019A 00 3.8mm sie-19 Ø14.5mm @14.5 Ø18mm Silicone grommet for thermal fuse and wires output, for cartridge heaters dia. 16 mm Silicone boot for TCO pocket mounting %2" disc thermostat protection boot, for dia. 5 to 8 mm cable %2.5 x 4.3 mm to 3 x 4.8 mm Many disc thermostat protection boots have been developed for heat tracing applications, and can be used on thermostats for incorporations, see catalogue N°3 Brackets and accessories for disc thermostats 9BBAE100000017A 9BBAE100000018A 9BBAE100000019A 9BBAE1000000011C 9BBBT100000006A @18.2m \$3.64 Black polypropylene boot for epoxy potting on ½"disc thermostat. Can be used with bracket 9BBAE1000000011C Large stainless steel extended mobile bracket for 1/2" disc thermostat with boot 9BBBT100000006A Stainless steel bracket for silicone cap 9BBJO3000004019A Stainless steel extended mobile bracket for 1/2" disc thermostat Large flat bracket, stainless steel, for ½"disc thermostat 9BBBT1M00ELH025D BBAE1000000040A 9BBAE1000000041A 9BBAE100000015A 6Y4903RESET90 R62.5mm 1.2mm Two ½" disc thermostat mounting bracket, center screw, stainless steel open type for thermostats with QC terminals ½" extended cup disc thermostat mounting bracket for pipe or tank mounting. Stainless steel. Must be spot welded on pipe. Specify pipe di Side manual reset button. This component allows to reset an ½" disc thermostat from the side Two ½" disc thermostat mounting bracket, center screw, stainless steel Two ½" disc thermostat mounting bracket, 3 screws, stainless steel Examples of special assemblies and wires harnesses of disc thermostats made in our factory (UL certified)

JPC

JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel: +33(0)1 60046644 Fax: +33(0)1 60048444 E-Mail: info@jpcfrance.fr Web: www.jpcfrance.fr

, products and components in this catalogue are made by Ultimheat alliance members.

less exceptionally specified by this logo

## Housings for temperature controls and heating elements



## These housings are described in catalogues 2, 3 and 4



## **Other catalogues**





Technical califogue for RSD department















JPC sas, 2 voie Gallo Romaine, ZAC de la Bonne Rencontre, 77860 Quincy Voisins, France Tel : +33(0)1 60046644 Fax : +33(0)1 60048444 E-Mail : info@jpcfrance.fr Web: www.jpcfrance.fr

NT3ENTSG01J2A MAJ20130402